

DLLA155P964 Injector Nozzle Technical File G1X9LLA155P964 G1Z17LLA155P964 G1HX16LA155P964 G1L1LLA155P964 G1S8LLA155P964



STRUMENT

SPARAT

 $S_1^{2,2}$

DLLA155P964 Injector Nozzle Technical File

38.50

 $S_1^{(0)}$

 $\otimes^{\mathbb{N}^1}$

Content

 $S^{\mathbb{R}}$

1. DLLA	155P96	4 Injecto	r Nozzie	muouu	- 20°	- 997	30	3.4				ి
1.4		55P904	Injector	Nozzle's	Applicat	i written	Part Nur	mber or Injecto			с. Дана 19	3
1.3		55P904	njector	Nozzle's	Applicat	on mon tions and	Dimonci	ions Para	notors			
			-		•							
1.9. 1.1.			njectori								с. 	دبام الا
31.1.0	DLLAI		njector i	Nozzie s	Customiz	ed Servic	.e	- State State	- 34 million			
								1				
								-9 ⁴				
								1				
								-94- ⁰⁰⁰ -				
2.3.	. DLLA1	55P964	Injector	Nozzle T	est Meas	urement						6
2,4.	. DLLA1	55P964	Injector	Nozzle's	Installati	on		i. 		ئەرىپىيەت ئەرىپىيە	0	6
2.5.	. DLLA1	55P964	Injector	Nozzle T	esting Af	ter Maint	enance.	-32-200				
								easurem				
2.7.	. DLLA1	55P964	Injector	Nozzle C	auses of	Damage	1	i	in salah	in san an a		8
								ng Metho				
3. DLLA	155P96	4 Injecto	r Nozzle	's Purcha	ise and D	elivery				5		9
3.1.			Injoctor	Nozzle's	Purchas	e Paymer	nt Metho	ods	ing a start of the	in state		9
	. DLLA1	55P964	injector	NOLLIE 5	1.30	100 March 100	100 C					
3.2.	155P96 DLLA1 DLLA1	55P964 55P964	Injector	Nozzle's	Main Sal	es Marke	et	- 1901. - 1901.				9
3.2. 3.3.	. DLLA1 . DLLA1 . DLLA1	55P964 55P964 55P964	Injector Injector	Nozzle's Nozzle's	Main Sal Declarat	es Marke ion Requ	et iirement	ts	. 1991 5			9 9
3.2. 3.3. 3.4.	DLLA1 DLLA1 DLLA1 DLLA1	55P964 55P964 55P964 55P964	Injector Injector Injector	Nozzle's Nozzle's Nozzle's	Main Sal Declarat Shipping	es Marke ion Requ Ways	et uirement	ts				9 9 9
3.3. 3.4. 3.5.	DLLA1 DLLA1 DLLA1	55P964 55P964 55P964	Injector Injector Injector	Nozzle's Nozzle's Nozzle's	Declarat Shipping Lead Tin	ion Requ Ways	uirement	s	and a constant	and a second		9 9 9
3.3. 3.4. 3.5. 3.6.	DLLA1 DLLA1 DLLA1 DLLA1	55P964 55P964 55P964 55P964	Injector Injector Injector Injector	Nozzle's Nozzle's Nozzle's Nozzle's	Declarat Shipping Lead Tin Logistic	ion Requ Ways ne s Time fo	urement r Destina	ts ation Out	t of Chin	a's Areas		9 9 9 9
3.3. 3.4. 3.5. 3.6.	DLLA1 DLLA1 DLLA1 DLLA1	55P964 55P964 55P964 55P964	Injector Injector Injector Injector	Nozzle's Nozzle's Nozzle's Nozzle's	Declarat Shipping Lead Tin Logistic	ion Requ Ways ne s Time fo	urement r Destina	ts ation Out	t of Chin	a's Areas		9 9 9 9
3.3. 3.4. 3.5. 3.6. 3.7. 4. DLLA	DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 DLLA1	55P964 55P964 55P964 55P964 55P964 4 Injecto	Injector Injector Injector Injector Injector	Nozzle's Nozzle's Nozzle's Nozzle's Nozzle's s Storage	Declarat Shipping Lead Tin Logistic Packing	ion Requ Ways ne s Time fo d	iirement r Destina	ts ation Out	t of Chin	a's Areas		9 9 9 10 11
3.3. 3.4. 3.5. 3.6. 3.7. 4. DLLA 5 Compa	DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 DLLA1	55P964 55P964 55P964 55P964 55P964 4 Injector mation	Injector Injector Injector Injector Nozzle'	Nozzle's Nozzle's Nozzle's Nozzle's Nozzle's s Storage	Declarat Shipping Lead Tin Logistic Packing. Standar	ion Requ Ways es Time fo d	iirement r Destina	ts ation Out	t of Chin	a's Areas		9 9 9 10 11 12
3.3. 3.4. 3.5. 3.6. 3.7. 4. DLLA 5 Compa	DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 DLLA1	55P964 55P964 55P964 55P964 55P964 4 Injector mation	Injector Injector Injector Injector Nozzle'	Nozzle's Nozzle's Nozzle's Nozzle's Nozzle's s Storage	Declarat Shipping Lead Tin Logistic Packing. Standar	ion Requ Ways es Time fo d	iirement r Destina	ts ation Out	t of Chin	a's Areas		9 9 9 10 11 12
3.3. 3.4. 3.5. 3.6. 3.7. 4. DLLA 5 Compa	DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 DLLA1	55P964 55P964 55P964 55P964 55P964 4 Injector mation	Injector Injector Injector Injector Nozzle'	Nozzle's Nozzle's Nozzle's Nozzle's Nozzle's s Storage	Declarat Shipping Lead Tin Logistic Packing. Standar	ion Requ Ways es Time fo d	iirement r Destina	ts ation Out	t of Chin	a's Areas		9 9 9 10 11 12
3.3. 3.4. 3.5. 3.6. 3.7. 4. DLLA 5 Compa	DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 155P96- any Infor Compar Sales-m	55P964 55P964 55P964 55P964 55P964 4 Injector mation ny Introc en's Con	Injector Injector Injector Injector Nozzle' Nozzle' Iuction	Nozzle's Nozzle's Nozzle's Nozzle's Nozzle's s Storage	Declarat Shipping Lead Tin Logistic Packing. Standar	ion Requ Ways es Time fo d	iirement r Destina	ts ation Out	t of Chin	a's Areas		9 9 9 10 11 12
3.3. 3.4. 3.5. 3.6. 3.7. 4. DLLA 5.Compa 5.1. 5.2.	DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 155P96- any Infor Compar Sales-m	55P964 55P964 55P964 55P964 55P964 4 Injector mation ny Introc en's Con	Injector Injector Injector Injector Nozzle' Nozzle' Iuction	Nozzle's Nozzle's Nozzle's Nozzle's Nozzle's s Storage	Declarat Shipping Lead Tin Logistic Packing. Standar	ion Requ Ways es Time fo d	iirement r Destina	ts ation Out	t of Chin	a's Areas		9 9 9 10 11 12
3.3. 3.4. 3.5. 3.6. 3.7. 4. DLLA 5.Compa 5.1. 5.2. 6. Copyi	DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 S5P96 any Infor Compar Sales-m right Stat	55P964 55P964 55P964 55P964 4 Injector mation ny Introc en's Con ement	Injector Injector Injector Injector Nozzle's Iuction	Nozzle's Nozzle's Nozzle's Nozzle's s Storage rmation.	Declarat Shipping Lead Tin Logistic Packing.	ion Requ Ways nes Time fo d	irement r Destina	ation Out	t of Chin	a's Areas		9 9 9 10 11 12 12 12 13
3.3. 3.4. 3.5. 3.6. 3.7. 4. DLLA 5.Compa 5.1. 5.2. 6. Copyi	DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 S5P96 any Infor Compar Sales-m right Stat	55P964 55P964 55P964 55P964 4 Injector mation ny Introc en's Con ement	Injector Injector Injector Injector Nozzle's Iuction	Nozzle's Nozzle's Nozzle's Nozzle's s Storage rmation.	Declarat Shipping Lead Tin Logistic Packing.	ion Requ Ways nes Time fo d	irement r Destina	ation Out	t of Chin	a's Areas		9 9 9 10 11 12 12 12 13
3.3. 3.4. 3.5. 3.6. 3.7. 4. DLLA 5.Compa 5.1. 5.2. 6. Copyi	DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 S5P96 any Infor Compar Sales-m right Stat	55P964 55P964 55P964 55P964 4 Injector mation ny Introc en's Con ement	Injector Injector Injector Injector Nozzle's Iuction	Nozzle's Nozzle's Nozzle's Nozzle's s Storage rmation.	Declarat Shipping Lead Tin Logistic Packing.	ion Requ Ways nes Time fo d	irement r Destina	ation Out	t of Chin	a's Areas		9 9 9 10 11 12 12 12 13
3.3. 3.4. 3.5. 3.6. 3.7. 4. DLLA 5.Compa 5.1. 5.2. 6. Copyr	DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 S5P96- any Infor Compat Sales-m right Stat	55P964 55P964 55P964 55P964 4 Injector mation ny Introc en's Con cement	Injector Injector Injector Injector Nozzle' luction	Nozzle's Nozzle's Nozzle's Nozzle's s Storage	Declarat Shipping Lead Tin Logistic Packing.	ion Requ Ways es Time fo d	irement r Destina	ation Out	t of Chin	a's Areas		
3.3. 3.4. 3.5. 3.6. 3.7. 4. DLLA 5.Compa 5.1. 5.2. 6. Copyr	DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 S5P96- any Infor Compat Sales-m right Stat	55P964 55P964 55P964 55P964 4 Injector mation ny Introc en's Con cement	Injector Injector Injector Injector Nozzle' luction	Nozzle's Nozzle's Nozzle's Nozzle's s Storage	Declarat Shipping Lead Tin Logistic Packing.	ion Requ Ways es Time fo d	irement r Destina	ation Out	t of Chin	a's Areas		
3.3. 3.4. 3.5. 3.6. 3.7. 4. DLLA 5.Compa 5.1. 5.2. 6. Copyr	DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 S5P96- any Infor Compat Sales-m right Stat	55P964 55P964 55P964 55P964 4 Injector mation ny Introc en's Con cement	Injector Injector Injector Injector Nozzle' luction	Nozzle's Nozzle's Nozzle's Nozzle's s Storage	Declarat Shipping Lead Tin Logistic Packing.	ion Requ Ways es Time fo d	irement r Destina	ation Out	t of Chin	a's Areas		
3.3. 3.4. 3.5. 3.6. 3.7. 4. DLLA 5.Compa 5.1. 5.2. 6. Copyr	DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 S5P96- any Infor Compat Sales-m right Stat	55P964 55P964 55P964 55P964 4 Injector mation ny Introc en's Con-	Injector Injector Injector Injector Nozzle' Iuction	Nozzle's Nozzle's Nozzle's Nozzle's s Storage	Declarat Shipping Lead Tin Logistic Packing. Standar	ion Requ Ways s Time fo	irement r Destina	ation Out	t of Chin	a's Areas		
3.3. 3.4. 3.5. 3.6. 3.7. 4. DLLA 5.Compa 5.1. 5.2. 6. Copyr	DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 S5P96- any Infor Compat Sales-m right Stat	55P964 55P964 55P964 55P964 4 Injector mation ny Introc en's Con-	Injector Injector Injector Injector Nozzle' Iuction	Nozzle's Nozzle's Nozzle's Nozzle's s Storage	Declarat Shipping Lead Tin Logistic Packing. Standar	ion Requ Ways s Time fo	irement r Destina	ation Out	t of Chin Stand	a's Areas		
3.3. 3.4. 3.5. 3.6. 3.7. 4. DLLA 5.Compa 5.1. 5.2. 6. Copyr	DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 S5P96- any Infor Compat Sales-m right Stat	55P964 55P964 55P964 55P964 4 Injector mation ny Introc en's Con-	Injector Injector Injector Injector Nozzle' Iuction	Nozzle's Nozzle's Nozzle's Nozzle's s Storage	Declarat Shipping Lead Tin Logistic Packing. Standar	ion Requ Ways s Time fo	irement r Destina	ation Out	t of Chin Stand	a's Areas		
3.3. 3.4. 3.5. 3.6. 3.7. 4. DLLA 5.Compa 5.1. 5.2. 6. Copyi	DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 S5P96- any Infor Compa Sales-m right Stat	55P964 55P964 55P964 55P964 4 Injectol mation ny Introc en's Con tement	Injector Injector Injector Injector Nozzle'	Nozzle's Nozzle's Nozzle's Nozzle's s Storage	Declarat Shipping Lead Tin Logistic Packing.	ion Requ Ways s Time fo d	r Destina	ation Out	t of Chin Shares	a's Areas		9 9 9 10 11 12 12 12 13
3.3. 3.4. 3.5. 3.6. 3.7. 4. DLLA 5.Compa 5.1. 5.2. 6. Copyi	DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 S5P96- any Infor Compa Sales-m right Stat	55P964 55P964 55P964 55P964 4 Injectol mation ny Introc en's Con tement	Injector Injector Injector Injector Nozzle'	Nozzle's Nozzle's Nozzle's Nozzle's s Storage	Declarat Shipping Lead Tin Logistic Packing.	ion Requ Ways s Time fo d	r Destina	ation Out	t of Chin Shares	a's Areas		9 9 9 10 11 12 12 12 13
3.3. 3.4. 3.5. 3.6. 3.7. 4. DLLA 5.Compa 5.1. 5.2. 6. Copyi	DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 S5P96- any Infor Compa Sales-m right Stat	55P964 55P964 55P964 55P964 4 Injectol mation ny Introc en's Con tement	Injector Injector Injector Injector Nozzle'	Nozzle's Nozzle's Nozzle's Nozzle's s Storage	Declarat Shipping Lead Tin Logistic Packing.	ion Requ Ways s Time fo d	r Destina	ation Out	t of Chin Shares	a's Areas		9 9 9 10 11 12 12 12 13
3.3. 3.4. 3.5. 3.6. 3.7. 4. DLLA 5.Compa 5.1. 5.2. 6. Copyi	DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 DLLA1 S5P96- any Infor Compa Sales-m right Stat	55P964 55P964 55P964 55P964 4 Injectol mation ny Introc en's Con tement	Injector Injector Injector Injector Nozzle' Iuction tact Info	Nozzle's Nozzle's Nozzle's Nozzle's s Storage rmation.	Declarat Shipping Lead Tin Logistic Packing.	ion Requ Ways s Time fo d	irement r Destina	ation Out	t of Chin School	a's Areas		9 9 9 10 11 12 12 12 12 13

1. DLLA155P964 Injector Nozzle Introduction

1.1. DLLA155P964 Injector Nozzle's Basic Information

Juni Title Juni	Common Rail Injector Nozzle DLLA155P964 China made new	Brand	17.75 1810
SKU1	G1X9LLA155P964	XINGMA	200
SKU2	G1Z17LLA155P964	LIWEI	100
SKU3 SKU3	G1HX16LA155P964	Shumatt	90' - 41 ⁰
SKU4	G1L1LLA155P964	China made	
SKU5 SKU5	G1S8LLA155P964	China made new	ant i A

1.2. DLLA155P964 Injector Nozzle's Common Written Part Number

		6 N
Injector Nozzle Order Number	Injector Nozzle Engraved Number	and a star
		de.r
093400-9600	DLLA155P964	
a start a start a start a start a start	with with with with with with	e
all all all all all all	المحالي المراقير المراقير المحالير المحالين المراقير	- 19 M

1.3. DLLA155P964 Injector Nozzle's Application Information for Injectors

(1) DLLA155P964 Injector Nozzle's Application for Injectors Part Number

Injector Part Number	Injector Series	System Pressure	Re-manufactured Part Number	System Pressure	Str. Str.
095000-6790	G2		and all the state of the second	and all all all	and and
(2) DLLA155PG	964 Injector No	zzle's Car Model Ma	atching Information	. So	200

Injector Part Number	Car Model	STATE STREET, STR
095000-6790	D28001801	

(3) DLLA155P964 Injector Nozzle Part Number Common Writing

all in

093400-9640, DLLA155P964, DLLA 155 P 964, DLLA155 P 964, DLLA155P 964, DLLA 155 P964, DLLA 155P964, DLLA 155P964

1.4. DLLA155P964 Injector Nozzle's Specifications and Dimensions Parameters

Injector Nozzle Size: 6 cm*1.5cm *1.5 cm

Injector Nozzle Barrel Dimensions: 7 cm *2 cm *2 cm

- Single Injector Nozzle Weight: 0.03kg
- Injector Nozzle 10 PCS Per Box: 10 cm *8 cm *4cm

Injector Nozzle Weight 10 PCS Per Box : 0.3kg

Injector Nozzle Quality: China Made New Injector Nozzle Injector Nozzle MOQ: 10 PCS

1.5. DLLA155P964 Injector Nozzle Quality Control

(1) Injector Nozzle Testing

All parts of the injector nozzle are subjected to precision testing, high temperature testing, low temperature testing, withstand pressure testing, leakage testing, durability testing, and various working conditions testing.

18 C -

(2) Injector Nozzle Inspection

The factory inspection of the injector nozzle is undergone full inspection, random inspection, and batch inspection three inspections. Different brands of test benches are used to test the same injector nozzle for a total of no less than three times for factory inspection, and the fuel injector installation testing environment


are progressed in dust-free workshop.

(3) Injector Nozzle Installation

When matching the valve cap and valve steam, Shumatt strictly complies with the standard of valve cap and valve stem clearance technical indicators to ensure that each valve assembly meets the factory standards and use standards.

1.6. DLLA155P964 Injector Nozzle's Customized Service

(1) Injector Nozzle's Customized Service: Meet the customized needs of OEM manufacturers for shell lettering (logo, nozzle part number, date and series number), nozzle without lettering, nozzle tube, nozzle box customized etc.



(2) Injector Nozzle's Customized Service Quantity Requirements:

The purchased of Customized injector nozzle's shell lettering or without lettering are no less than 100 pieces. The purchased of Customized injector nozzle tubes are no less than 2000-3000 pieces.

The purchased of customized injector nozzle boxes are no less than 1000 pieces.

Customized products involve the need of specify logo, the OEM manufacturer needs to provide trademark authorization and the sample of logo image file.

A Once the customized injector nozzle is sold, it can't be returned or exchanged if there is no quality problems.

1.7. DLLA155P964 Injector Nozzle's Packing List

(1) Injector Nozzle's Spare Parts List

	of NOZZIE'S Spare Parts List	and the state of the	<u>- 1887 - 1887 - 1887 - 1886</u>
No.	1 1	2	an a
STANDAL SA	and the set that	51 ⁰ 1 ¹ / ₁	そう 大轨喷油嘴 S Common Rail Injector Nealler
Image Sh ^{ijan (1}		st ^e	ALL BART A
Name	Injector Nozzle Assy	Nozzle Tube	Injector Nozzle Box
Description	Injector Nozzle Part Number DLLA155P964	Prevent Nozzle Rusting and Damaging from Collision	10 PCS/Box
and the second sec	nors are prohibited to use fuel ector nozzle box is recyclable a	and a second a second a second	e packing box to avoid injury.

A Injector nozzle barrels is non-degradable material, please dispose of it properly after use.

P. DU A1EED064 Injector Noralo's Warranty Instructions

1.8. DLLA155P964 Injector Nozzle's Warranty Instructions

(1) . Injector Nozzle's Warranty Conditions and Instructions

It is necessary to provide pictures, videos, or test reports detected by the injector nozzle inspection equipment when the injector nozzle is abnormal during use as evidence to feed back to the salesman.

Abnormal conditions are properly explained such as: 1.Smoke, 2. Engine shake, 3. Difficulty starting the engine, 4. Engine noise, 5. oil leakage etc.

(2) . Injector Nozzle Warranty Coverage

Within 15 days after customer receives the DLLA155P964 injector nozzle if there is a performance failure and the product has no appearance damage, customer can choose to replace it or repair it;

If the DLLA155P964 injector nozzle has performance problems during the warranty period (6-12 months), and it is confirmed that it is product's problems after testing, you can contact our salesmen to replace the same model or a reworked product with the same performance for free;

If the injector house has obvious scratches, it can only be repaired and it will be returned as it is if the product is confirmed to be fault-free. SPARATE

(3) . Injector Nozzle Out of Warranty Coverage

The warranty period has expired.

Injector nozzle failure caused by high temperature, high pressure, humidity, rain and snow, saline-alkali NOPP. $_{B} \mathcal{B}^{(2)}$ land, earthquake, and used in abnormal environment.

Injector nozzle damage caused by man-made reasons (throwing, strong magnetic field magnetization, set fire).

Injector nozzle failure or injector damage caused by non-injector design, technology, manufacturing, quality and other issues.

Injector nozzle failure due to system pressure exceeding system approved pressure.

Injector nozzle failure caused by system voltage exceeding approved voltage.

Injector nozzle failure caused by impurities (water, lead, aluminum powder, iron powder, sulfide) in the system fuel exceeding the standard requirements. 100 100 100

Injector nozzle failure caused by not installing according to the tightening torque specified in the vehicle engine maintenance manual (the tightening torque is too large or too small).

Injector nozzle failure caused by not following the installation angle specified in the injector maintenance St. Star alone alone alone along along along manual. - di^{nger} - di^g

Injector nozzle failure caused by not following the cleaning requirements specified in the injector maintenance maintenance manual. . S.C.

Injector nozzle failure caused by failure to replace consumable parts as specified in the injector maintenance manual.

1.9. DLLA155P964 Injector Nozzle's Manufacturer

Injector nozzle's manufacturer: Shenzhen Shumatt Technology Co., Ltd

2. DLLA155P964 Injector Nozzle's Technical Support

 (1) Clean the injector nozzle in an ultrasonic cleaner for 3-5 minutes before installation, so as to make the stains, dust, rust-proof oil oxides paraffin base, parabthenic to naphthenate, zinc naphthenate, sodium petroleum sulfonate, barium petroleum sulfonate, calcium petroleum sulfonate, tallow diamine trioleate, rosinamine on the surface of the injector nozzle fall Sh^{afti} " SHERE SHERE SHERE SHERE SHERE SHERE - 13²⁵⁰ Star Star $-2\delta^{2}$

(2) Use compressed air to clean the cleaning fluid attached to the surface of the injector nozzle after 13. cleaning, and clean it up to the standard of use.

2.2. DLLA155P964 Injector Nozzle Inspection.

(1) Check whether there is deformation, cracking, thread damage, quenching, leakage and rust in the guide sleeve, spring, gasket and tight cap of the nozzle. The tight cap of the nozzle must be replaced after being disassembled for more than 5 times, as shown in the following.



(2) Replace the tight cap of the nozzle and the copper gasket of the injector nozzle

(3) Check whether the gap between the nozzle needle and the nozzle shell is within the standard range and whether it reaches the standard for use

- All parts should be examined for wear under a microscope at least 20 times larger
- Nozzle tight cap deformation, cracking, thread damage, quenching, leakage, will lead to black smoke A vehicle cap, fuel injector damage.
- Injector opening pressure greater than or less than the specified range may cause injector damage.
- Failure to replace wearing parts in time during maintenance may lead to fuel injector damage.

2.3. DLLA155P964 Injector Nozzle Test Measurement -91,60

(1) Nozzle opening pressure test

Test whether the opening pressure range of the nozzle is within the range specified in the injector maintenance manual (to be verified), if not within the normal range, adjust the nozzle spring to adjust the gasket

- If the value is greater than normal, reduce the oil nozzle spring adjusting gasket; if the value is less than normal, increase the oil nozzle spring adjusting gasket.
- (2) Stroke Measurement of Nozzle Needle Valve

Use a measuring tool to measure whether the stroke of the nozzle needle valve is within the range (15-45um) specified in the injector maintenance manual. If not, adjust the stroke of the nozzle to adjust the gasket.



A If the value is greater than normal, thicken the gasket for oil-nozzle needle valve lift adjustment; if the value is less than normal, reduce the gasket for oil-nozzle needle valve lift adjustment

2.4. DLLA155P964 Injector Nozzle's Installation

(1) Tightening torque of injector nozzle

The torque lever and tightening moment specified in the injector maintenance manual must be installed when the injector nozzle is installed. (50Nm)

Mob/Whatsapp: +86 13410541523 Email : ruby@shumatt.com © 2022 Shenzhen Shumatt Technology Co., Ltd

Tel: +8675523215133 Website : www.shumatt.com

The The Tree .

 $\oplus^{(0)}$



The tightening torque of the nozzle cap must be installed in accordance with the tightening torque specified in the injector maintenance manual

2.5. DLLA155P964 Injector Nozzle Testing After Maintenance

(1) After installation, it needs to be tested on the test bench.



The correct injector type should be selected for testing

 $(2)\,$. The test results need to be ensured that the following items are within the standard data range of the test stand.

LEAK TEST: Test whether sealing test is up to standard or not

In this step, no injector collector should be installed at the nozzle during the test so as to observe whether the nozzle is dripping oil, meanwhile observe that all joints are no oil leaking. The static oil return of the test should not exceed 8mm2/H, otherwise, you need to check whether the high-pressure sealing ring, valve assembly, and stroke parameters of the injector are within the standard range.

VL: Test whether full load oil (main injection, high speed) is up to standard or not

This step needs to be combined with vehicle driving conditions, such as power, fuel consumption and smoke as well as the maintenance of the engine, if there is situation of insufficient power, fuel consumption is high, thick black smoke and irregularly maintenance of the engine, the engine needs to be maintained according to the maintenance handbook at very first time.

situations to ensure the injector is normal. After make sure the injector works normal, you need to reduce the armature stroke if too much oil injection, and increase the armature stroke if too little oil injection.

TL\EM: Test whether the torque point, emission point, exhaust limit, fuel supply reach standard or not

Through this test, it is detected that when the oil injection is too little, the engine's acceleration is slow, vice versa, when the oil injection is too much, the engine's acceleration will produce black smoke and the engine excessive exhaust emissions.

njector nozzle spring force gasket, armature stroke, lift gasket and solenoid valve spring force gasket and solenoid valve spring force gasket determine whether exhaust restriction and injector fuel supply reach standard على المحمد المحمد and solenoid valve spring force gasket and so

LL: Test if the idle fuel supply reaches the standard

This test detects oil injection is too much will cause engine idle smoke, otherwise if the oil injection too little will cause engine idling easy to stall, or difficult to start.

The uneven of oil injection causes the unstable rotation speed of engine , making noise, and increase the engine swing in the acceleration process.

Mob/Whatsapp: +86 13410541523 Email : <u>ruby@shumatt.com</u> © 2022 Shenzhen Shumatt Technology Co., Ltd Tel: +8675523215133 Website : www.shumatt.com

Shenzhen Shumatt Technology Co., Ltd SHUMATT Each injector error should be controlled within 2mm3/HH when adjusting. Idle speed fuel supply quantity mainly by adjusting the nozzle spring force gasket. VE: Test whether the pre-injection meets the standard This test detects when oil injection is too much will cause cylinder knocking while the engine is working and the exhaust emissions is not up to standard (smoke). 🚚 While when oil injection is too little will cause big noise while the engine is working, the engine is difficult to start, the engine weak acceleration, slow response of injector. Each injector error should be controlled within 0.5mm3/HH when adjusting. $\mathcal{G}^{(i)}$ 2.6. DLLA155P964 Injector Nozzle List of Tools Used During Measurement and Installation Image 🖹 **CRT084 CRT079** SKU **CRT220** Fuel injector stroke measuring WREET Torque wrench: 19-110nm 1/2 tool: It is used to control tightening is used to measure buffer Micrometer: is used to Description force and angle during stroke of fuel injector, measure gasket thickness SP JOR installation armature stroke and remaining air gap Image NUMPER SKU CRT281 Common rail injector test Ultrasonic cleaning machine: bench: Description is used for cleaning fuel check the injector working injector and parts art i condition

2.7. DLLA155P964 Injector Nozzle Causes of Damage

(1) Fuel injector nozzle failure caused by impurities (water, lead, aluminum powder, iron powder, sulfide) in fuel exceeding standard requirements.

 $(\mathbf{2})~$ The nozzle is normally worn due to long time working under high temperature

(3) Nozzle needle wear leads to oil hole blockage, insufficient fuel injection injector cannot work properly.

Nozzle needle wear leads to oil hole blockage, insufficient fuel injection injector can't work properly.

▲ The wear of the nozzle leads to the increase of fuel quantity, resulting in black smoke of the vehicle, and the fuel injector can't work properly when it is serious.

If the nozzle needle can't move smoothly stuck may cause serious damage to the injector nozzle

▲ The rusting of the nozzle spring leads to spring fracture and black smoke from the vehicle.

A The opening pressure of the nozzle decreases, and the oil quantity of the injector increases, leading to black smoke of the vehicle, and the injector can't work properly when it is serious.

▲ Oil-nozzle needle valve lift adjustment gasket wear oil-nozzle needle valve stroke becomes larger, the fuel injector oil quantity becomes larger, resulting in black smoke of vehicles, resulting in the fuel injector can't work properly when serious.

▲The cracking of the nozzle cap is caused by high intensity work under high temperature.

the little little. The little little, little, little, little, little, little, little, little, little,

2.8. DLLA155P964 Injector Nozzle Technical Support Obtaining Methods

(1) Injector Nozzle Technical File, visit http://shumatt.com to get the technical file 59.57⁸

(2) Injector Technical Videos

Facebook: Visit https://www.facebook.com/hison.li constantly follow can get more information.

YouTube: Visit https://www.youtube.com/channel/UCByvYBx7VjV mAfxh Hu-aw to get the technical videos, and can learn more information if you follow.

Shumatt: Visit <u>http://shumatt.com</u> to get the technical videos.

(3) Injector Nozzle Information Query Software

TruckBook Parts EPC APP, Android/Apple App Store download and install, visit http://shumatt.com to get the download and installation tutorial

(4) Search The injector nozzle test data through TruckBook Parts EPC APP.

3. DLLA155P964 Injector Nozzle's Purchase and Delivery.

3.1. DLLA155P964 Injector Nozzle's Purchase Payment Methods Payment Methods: T/T, PayPal, Alipay, WeChat

Please contact our salesmen for specific payment information.

3.2. DLLA155P964 Injector Nozzle's Main Sales Market.

Injector Nozzle's main sales markets: Asia, Europe, North America, South America, Africa etc.

0855

3.3. DLLA155P964 Injector Nozzle's Declaration Requirements

0555

St. Shumatt can assist customers to provide the following documents for import customs clearance: contract, invoice, packing list, bill of lading, insurance policy, certificate of origin, etc. 3.55.57

-2.500¹⁷ 3.4. DLLA155P964 Injector Nozzle's Shipping Ways

Destination in China areas: SF Express, Debon Express, the corresponding logistics company can be provided according to customer requirements in special cases.

Destinations out of China' s areas: DHL, UPS, FedEx, TNT air, ocean or other shipping methods required by customers.

3.5. DLLA155P964 Injector Nozzle's Lead Time

Lead time: Send out within 3 – 7 working days after receiving payment (Except for special products and special cases).

3.6. DLLA155P964 Injector Nozzle's Logistics Time for Destination Out of China's Areas **DHL Logistics Time:**

Thailand

Vietnam

Country or Regio Departure		Hong ong, China	Other Countries or Regions of Asia	Australia and Zealand		Europe	America	Other Countries
China's Mainlar	nd	7 Days	7 Days	8 Days	4	8 Days	8-12 Days	7-10 Days
JPS Logistics Tir	ne: Co	untry or	Region of Departur	e: China's Ma	inland	97 - 23 ⁵⁰	er - 21	1997 - a
Country of Destination	Estimate Arrival Ti		Country of Destination	Estimated Arrival Time	Cou	ntry of Desti	nation	Estimated Arrival Time
Japan	3 Days	and the second	UK AND	5-7 Days	Nº.	Egypt	S. All	5-7 Days
Turkey	5-7 Day	s	Singapore	3 Days		Switzerland	d L	5-7 Days
Bahrain	5-7 Day	s and	Latvia	7-10 Days	ų. 1	New Zealan	d	7-10 Days

3 Days

3-5 Days

5-7 Days

5-7 Davs

Sri Lanka

Romania

Austria

Estonia

5-7 Days

5-7 Days

SHUMT	She	enzhen Shumatt	Technolog	gy Co., Ltd	
Malaysia	3-5 Days	Israel	5-7 Days	Mexico	7-10 Days
France	5-7 Days	America	5-7 Days	United Arab Emirates	5-7 Days
Italy	5-7 Days	Netherlands	5-7 Days	Bengal	7-10 Days
Lebanon	5-7 Days	Philippine	3-5 Days	Greece	7-10 Days
South Korea	3 Days	Star Spains	5-7 Days	S Myanmar	5-7 Days
Canada	5-7 Days	Germany	5-7 Days	Saudi Arabia	7-10 Days
Portugal	5-7 Days	Australia	5-7 Days	South Africa	7-10 Days
Denmark	5-7 Days	Belgium	5-7 Days	Ukraine	7-10 Days
India	7-10 Days	Qatar	7-10 Days	Poland	5-7 Days
Indonesia	3-5 Days	Morocco	7-10 Days	Pakistan	7-10 Days
Kuwait	7-10 Days	and a start a start	and a star	a start a start as	and a start of

The logistics time is for reference only, subjects are according to the actual arrival.

3.7. DLLA155P964 Injector Nozzle's Packing

Domestic express packaging: Usually wrapped in waterproof scotch tape, such as picture No.2. **International express packaging:** Wrapped with waterproof yellow tape After wrapping the black protective film, such as picture No. 3.

Pallet Shipping: Use fumigation free and recycling trays that meet export requirements, and use white wrapping protective film to wrap and bind with cable ties for the outside, such as picture No. 4, Also, the products can be packaged according to customers' requirements.

A The packing tray is made of plastic and can be recycled.

Transparent tape, yellow tape, black wrapping protective film, white wrapping protective film are non-degradable materials, please dispose of them properly.

Minors are prohibited from using transparent tape, yellow tape, black wrapping protective film, and white wrapping protective film to avoid personal injury.



Mob/Whatsapp: +86 13410541523 Email : <u>ruby@shumatt.com</u> © 2022 Shenzhen Shumatt Technology Co., Ltd Tel: +8675523215133 Website : www.shumatt.com



Pallet Shipping: Use pallet that meet export requirements, and use white wrapping protective film to wrap and bind with cable ties

4. DLLA155P964 Injector Nozzle's Storage Standard

(1) Choose a suitable storage place

The warehouse and cargo yard where the injector nozzles are stored should be kept clean and dry, and away from the factory buildings that generate harmful gases and dust; do not mix with acid, alkali, salt and other substances; the storage place should have a good drainage system; the cargo yard should be flattened with gravel or furnace ash etc. to enhance the water permeability of the surface layer to keep the reservoir area dry.

(2) Strict requirements of warehousing

Strict inspections should be carried out when the injector nozzles are put into storage, the surface cleaning work should be done well to remove water traces, oil stains, ash and other dirt, remove the rust and do anti-rust treatment in time. Packaged nozzles must be protected from damage.

(3) Keep the warehouse dry and preventing moisture

The relative humidity is usually below 70% for the injector nozzles placed in the room, and the corrosion of the injector nozzles is significantly reduced.

Injector nozzles must be stored in the warehouse, and they are forbidden to store in the same warehouse with commodities with high water content.

(4) Stack Properly

After the injector nozzle is exposed to rain, the corrosion rate will increase significantly. The purpose of sealing is to isolate the injector from rainwater and humid air, so the warehouse window should be checked in time to avoid rainwater entering the warehouse

If the injector nozzle package is damaged, it should be repaired or replaced; when the package is damp, the packaging material should be dried; if the original anti-corrosion and oil applied at the factory is found to be damaged or dried up, it should be cleaned and re-applied oil in time.

A It is forbidden to leave the injector nozzle exposed in the air for a long time.

It is forbidden to store acid, alkali, salt and other substances together with the injector nozzle.
The unpacked diesel injector nozzle must be rust-proof during secondary storage.

and the second and the se



SHUMATT



Mob Phone/WeChat: +86-13410541523

HK Telephone: +852-67653519

Telephone: +86-755-23215133

Email: ruby@shumatt.com

Website: www.shumatt.net

SPARS Shenzhen Office: 11-12, Floor 14, Building 13, Qinchengda Building, Exit A, Honglang North Subway Station, and Con and. Bao'an District, Shenzhen, China's Mainland 1997 and the

Shenzhen Office: Room 428-430, Building B, Huafeng Zhigu Technology Industrial Park, Exit B, Fuyong Metro Station, Bao'an District, Shenzhen, China's Mainland

Hong Kong Office: Jianfa Street Industrial Zone, Tuen Mun, New Territories, Hong Kong, China After-sales Service Address: Please contact our salesmen to obtain and provide the corresponding product maintenance reasons (Reference: <u>1.8. DLLA155P964 Injector Warranty Instructions</u>)

No.	Name	WeChat/ WhatsApp	Email	Facebook	YouTube
1	Ruby	+86-13410541523	ruby@shumatt.com	Hison Li	Hison Li
2	s lvy store	+86-18025309821	sales@shumatt.com	Ivy Shumatt	Shumatt IVY
3	Rebecca	+86-18025349821	sales01@shumatt.com	Rebecca SHUMATT	SHUMATT Rebecca
4.00	Janny	+86-18028749821	sales02@shumatt.com	Janny shumatt	Janny Shumatt
5	Sam	+86-13316859821	Sales8@shumatt.com	Shumatt Sam	Sam Shumatt
6	Natalie	+86- 18938945856	sales15@shumatt.com	Shumatt Natalie	Lin Natalie
7	Ada	+86-1342286353	sales5@shumatt.com	Shumatt Ada	Ada Shumatt
80.00	Hison Li	+86-18318811871	web@shumatt.com	Hison Li	Hison Li
9	Mecca	+86-18938948618	sales11@shumatt.com	Shumatt Mecca	Shumatt Mecca
10	Eric	+86 18319033618	sales3@shumatt.com		
11 , 3 ⁰⁰	Wayne (Joaquín en español)	+86-13316959821	wayne@shumatt.com	shumattwayne	Wayne Shumatt
12	Sylvia	+86 18312499884	sales6@shumatt.com		

Mob/Whatsapp: +86 13410541523 Email: ruby@shumatt.com © 2022 Shenzhen Shumatt Technology Co., Ltd

Tel: +8675523215133 Website : www.shumatt.com

12 / 13

6. Copyright Statement

The copyright of any contents in "*DLLA155P964 Injector Nozzle Technical Fail*" (including but not limited to parameters, data, text, charts, images, sounds or videos, etc.) provided in belong to Shenzhen Shumatt Technology Co., Ltd. Without the prior written permission of Shenzhen Shumatt Technology Co., Ltd., you are not allowed to modify any contents in "*DLLA155P964 Injector Nozzle Technical Fail*" in any way. At the same time, any conditions to spread, re-post or display the contents in "*DLLA155P964 Injector Nozzle Technical Fail*" should indicate that the cited article is from Shenzhen Shumatt Technology Co., Ltd., Any actions failure to follow above conditions to use "*DLLA155P964 Injector Nozzle Technical Fail*" will violate the "*Copyright Law of the People's Republic of China*" and other laws and regulations that relevant international conventions.

 $\phi^{(i)}$ st^{uter} çi (î SAL DA $\phi_{i}^{(0)}$ $\phi^{(0)}$ Stoffe $\otimes^{[0]}$ giⁱⁱ SHARES