SHUMP!

SHUMF!

SHUMPY!

SHUMPY!

SHUMP!

SHUMP!

SHUMFIT

SHUMFITT

SHUMFITT

SHUMFITT

SHR

SH

SHR

SH

SH

SHUMFIT

SHUMFITT

SHUMFITT

SHUMFITT

SHR

SHUMP!



SHUMP!

SHUMFI!

SHUMFI!

SHUMP!

SHUMFITT

MATT

UMFITT

UMFITT

MATT

SHUMFITT

SHUMFIT

SHUMFITT

SHUMFITT

SHUMFITT

SHUMFITT

SHUMFIT

SHUMFITT

095030-6070 Injector Valve Stem G2 Series Technical File



SHUMFIT

SHUMFITT

SHUMFITT

SHUMFIT

SHUMFIT

SHUMFIT

SHUMFITT

SHAMPITT

TIFINE

SHUMFITT

SHUMATT

SHUMFIT

SHUMFIT

TIME

SHUMFITT

SHUMFITT

SHUMFITT

SHUMFITT

Times

Tel: +8675523215133 Website SHUMFITT SHUMFITT בייטטי 23215133 Website : <u>www.shumatt.com</u> Mob/Whatsapp: +86 13410541523 Email: ruby@shumatt.com

SHUMFITT

SHUMFITT

SHUMFIT

SHUMFIT

© 2024 Shenzhen Shumatt Technology Co., Ltd TIME

SHUMFITT

SHUMFITT

SHUMFIT

SHUMFIT



095030-6070 Injector Valve Stem G2 Series Technical File

Content

1. 095030-6070 Injector Valve Stem Introduction	
1.1. 095030-6070 Injector Valve Stem Basic Information	2
1.2. 095030-6070Injector Valve Stem Common Part Number	
1.3. 095030-6070 Injector Valve Stem Parameter	
1.4. 095030-6070 Injector Valve Stem Specifications and Dimensions	2
1.5. 095030-6070 Injector Valve Stem Quality Control	2
1.6. 095030-6070 Injector Valve Stem Customized Service	3
1.7. 095030-6070 Injector Valve Stem Package List&Size	3
1.8. 095030-6070Injector Valve Stem Testing Standard and Certificate	
1.9. 095030-6070Injector Valve Stem Warranty Description	
2. 095030-6070 Injector Valve Stem Technical Support	6
2.1. 095030-6070 Injector Valve Stem Measuring Tools	
2.2. 095030-6070 Injector Valve Stem Measuring Steps	7
2.3. 095030-6070 Injector Valve Stem Installation Precautions	7
2.4. Reasons For 095030-6070 Injector Valve Stem Not Working Normally	8
2.5. Causes of 095030-6070 Injector Valve Stem Being Damaged	8
2.6. 095030-6070 Injector Valve Stem Storage Standard	9
2.7. 095030-6070 Injector Valve Stem Technical Support Obtaining Methods	
3. 095030-6070 Injector Valve Stem Purchase and Delivery	10
3.1. 095030-6070 Injector Valve Stem Purchase Payment Term	10
3.2. 095030-6070 Injector Valve Stem Main Sales Markets	10
3.3. 095030-6070 Injector Valve Stem Declaration Requirements	
3.4. 095030-6070 Injector Valve Stem Shipping Ways	10
3.5. 095030-6070 Injector Valve Stem Lead time	10
3.6. 095030-6070 Injector Valve Stem Logistics Time for Destination Out of China's Areas	
3.7. 095030-6070 Injector Valve Stem Packing	
4. Company Information	13
4.1. Company Introduction	
4.2. Sale-men Contact Information	14
5 Copyright Statement	14

Mob/Whatsapp: +86 13410541523 Tel: +8675523215133

Email: ruby@shumatt.com

© 2024 Shenzhen Shumatt Technology Co., Ltd

Website: www.shumatt.com



095030-6070 Injector Valve Stem G2 Series Technical File

1. 095030-6070 Injector Valve Stem Introduction

1.1. 095030-6070 Injector Valve Stem Basic Information

Title	095030-6070 Injector Valve Stem China Made New
SKU	G1F150000560FG

1.2. 095030-6070Injector Valve Stem Common Part Number

(1) Injector Valve Stem Applicable Injector Model

Injector Valve Stem Part Number	OE Number
095000-056#	6218-11-3101

(2) Injector Valve Stem Matching Information

Vehicle Brand	Car Model	Engine Model	Production Date
KOMATSU	INDUSTRIAL	P140	0010

(3) Injector Valve Stem Part Number Common Writing

095000-0560, 095000-0561, 095000-0562, 095000-0563, 095000-0564, 095000-0565, 095000-0566, 095000-0567, 095000-0568, 095000-0569, 095000-056#, 095030-6070, 6218-11-3101

1.3. 095030-6070 Injector Valve Stem Parameter

Adaptation System: Common Rail System Injector Valve Stem Series: G2 Series

Injector Valve Stem Size: L60.7mm*

5mm

1.4. 095030-6070 Injector Valve Stem Specifications and Dimensions

Injector Valve StemSize: 14*1*1=25 cm³ (L*W*H=V)

Single Injector Valve Stem Weight: 20g

Injector Valve Stem Weight With Packaging: 25g
Injector Valve Stem Quality: China Made New

Injector Valve Stem Package Size: 14* 1cm *1m =143 (L*W*H=V)

Injector Valve StemType: High Pressure Common Rail Injector Valve Stem

Injector Valve Stem MOQ: 1pcs

1.5. 095030-6070 Injector Valve Stem Quality Control

(1) Injector Valve Stem Testing

All parts of the Injector valve stem have undergone electrical characteristics testing, precision testing, high temperature testing, low temperature testing, withstand pressure testing, leakage testing, durability testing, and various working conditions testing.

(2) Injector Valve Stem Installation

The injector valve stem production and installation process is quality controlled. Our company strictly

Mob/Whatsapp: +86 13410541523 Tel: +8675523215133

Email: ruby@shumatt.com Website: www.shumatt.com

follows the standard product installation data and product installation steps for installation, such as injector stroke test, injector solenoid valve tightening torque, injector nozzle tightening torque.

(3) Injector Valve Stem Inspection

The factory inspection of the injector valve stem has undergone three inspections: full inspection, random inspection, and batch inspection. Different brands of test benches are used to test the same injector valve stem for more than three times for factory inspection, and the injector valve stem installation testing environment are progressed in dust-free workshop.

1.6. 095030-6070 Injector Valve Stem Customized Service

(1) Injector Valve Stem Customized Service Coverage: Meet OEM manufacturers' customization needs for shell engraving, logo engraving, injector valve stem internal packaging, injector valve stem external packaging and labels, etc.

0 0		
No.	1	2
Image	Int'	
AIMPITT AIR	In I	The same same of
Name	Injector Valve Stem Engraving	Injector Valve Stem Packing&Label

(2) Injector Valve Stem Customized Service Requirements:

The purchase of customized injector valve stem is no less than 10 pieces.

The purchase of customized injector valve stem boxes is no less than 1000 pieces.

⚠ When the customized products involve the need of specify logo, the OEM manufacturer is asked to provide trademark authorization and the sample of logo image file.

• Once the customized injector valve stem is sold, it can't be returned or exchanged if there is no quality problems.

1.7. 095030-6070 Injector Valve Stem Package List&Size

(1) Injector Valve Stem Spare Parts List

R	No.	1	2	3
19	Reference Image	ATT SHOT	MATT SHUT	THE
. 2	Name	Injector Valve Stem	Injector Valve Stem Length	Injector Valve Stem diameter
1	Description	She She She	L57.63mm	Φ 4.3mm

▲ Minors are forbidden to use the injector assembly, O-ring, nozzle protective cover, injector house protective cover, oil return protective cover, VCI anti-rust bag, and air bubble bag to avoid personal injury.

O-ring and washer shim are disposable installation accessories, and need to be replaced for

Mob/Whatsapp: +86 13410541523 Tel: +8675523215133

Email: ruby@shumatt.com Website: www.shumatt.com

re-installation.

▲ The nozzle protective cover, the injector house protective cover, and the oil return protective cover are recyclable accessories that can be reused.

▲ VCI anti-rust bags and bubble bags are non-degradable materials. Please dispose of them properly after using.

▲ The injector and the installation parts should be coated with appropriate sealing oil during installation.

(2) Injector Valve Stem Package Size



Pic No.1

No.	Name	Injector Valve Stem Package Size (cm)		
1	Injector Valve Stem Package	14*1*1		

1.8. 095030-6070Injector Valve Stem Testing Standard and Certificate

We can provide the factory quality inspection test report of each injector valve stem to ensure that each injector valve stem delivered meets the engine performance indicators.

Mob/Whatsapp: +86 13410541523 Tel: +8675523215133

Email: ruby@shumatt.com Website: www.shumatt.com



Pic No.2

1.9. 095030-6070Injector Valve Stem Warranty Description

(1) Product Warranty Conditions and Instructions

It is necessary to provide pictures, videos, or test reports detected by the injector valve stem inspection equipment as evidence to feed back to the salesman when the injector valve stem is abnormal during using.

Abnormal conditions are properly explained such as: 1.Smoke, 2. Engine shake, 3. Difficulty starting the engine, 4. Engine noise, 5. Oil leakage etc.

(2) Injector Valve Stem Warranty Coverage

Within 15 days after customer receives the 095030-6070 injector valve stem, if there is a performance failure and the product has no appearance damage, customer can choose to replace it or repair it;

If the 095030-6070 injector valve stem has performance problems during the warranty period (6-12 months), and it is confirmed that it is product's problems after testing, you can contact our salesmen to replace the same model or a reworked product with the same performance for free;

If the injector valve stem has obvious scratches, it can only be repaired and it will be returned as it is if the product is confirmed to be fault-free.

▲ Tips: For products not covered by warranty, our company can provide paid maintenance services. For products after paid repaired, the same performance problem will have a free warranty period within 3 months from the date of repairing.

Mob/Whatsapp: +86 13410541523 Tel: +8675523215133

Email: ruby@shumatt.com

© 2024 Shenzhen Shumatt Technology Co., Ltd

Website: www.shumatt.com



(3) injector valve stem Out of Warranty Coverage

- 1 The warranty period has expired.
- ② Injector valve stem failure caused by high temperature, high pressure, humidity, rain and snow, saline-alkali land, earthquake, and used in abnormal environment.
- 3 Customer disassembles or repairs the injector valve stem personally resulting in damage to the injector valve stem.
- ④ Injector valve stem damage caused by man-made reasons (throwing, strong magnetic field magnetization, set fire).
- ⑤ Injector valve stem failure or injector valve stem damage caused by non-injector valve stem design, technology, manufacturing, quality and other issues.
 - ⑤ Injector valve stem failure due to system pressure exceeding system approved pressure.
 - ① Injector valve stem failure caused by system voltage exceeding approved voltage.
- 8 Injector valve stem failure caused by impurities (water, lead, aluminum powder, iron powder, sulfide) in the system fuel exceeding the standard requirements.
- Injector valve stem failure caused by not installing according to the tightening torque specified in the vehicle engine maintenance manual (the tightening torque is too large or too small).
- 10 Injector valve stem failure caused by not following the installation angle specified in the vehicle engine maintenance manual.
- 11 Injector valve stem failure caused by not following the cleaning requirements specified in the vehicle engine maintenance manual.
- 12 Injector valve stem failure caused by failure to replace consumable parts as specified in the vehicle engine maintenance manual.
- 13 Injector valve stem failure caused by not complying with the intake system fit clearance and exhaust system fit clearance requirements specified in the vehicle engine maintenance manual.
- 14 Failure to replace the consumable parts and the fitting clearance of the oil inlet system pipeline and the injector valve stem connection in accordance with the fuel intake system specified in the vehicle engine maintenance manual.


2. 095030-6070 Injector Valve Stem Technical Support

2.1. 095030-6070 Injector Valve Stem Measuring Tools

Mob/Whatsapp: +86 13410541523 Tel: +8675523215133

Email: ruby@shumatt.com Website: www.shumatt.com





Pic No.3

1. Inner diameter measuring claw	7. inch/mm metric and inch conversion button
2. Limit screw	8. OFF/ON power button
3. Battery installation place	9. ZERO button
4. Ruler body	10. Push roller
5. depth measurement	11. Button battery
6. depth measurement	/ Show Show Show Show Show

2.2. 095030-6070 Injector Valve Stem Measuring Steps



2.3. 095030-6070 Injector Valve Stem Installation Precautions

(1) The replacement of the injector valve stem must strictly follow the electrical system, the approved pressure of the low-pressure fuel intake system, the approved pressure of the high-pressure fuel circuit system, and fuel system replacement consumables requirements (including the low-pressure

Mob/Whatsapp: +86 13410541523 Tel: +8675523215133

Email: <u>ruby@shumatt.com</u> Website: <u>www.shumatt.com</u>



fuel circuit system filter and the high-pressure fuel circuit) specified in the vehicle engine maintenance manual.

- (2) Replacement of wearing parts of the fuel system, cleaning requirements for the connection between the fuel system and the injector valve stem, the fitting clearance of the injector valve stem connection, the installation angle and tightening torque of the injector valve stem, the fitting clearance of the intake system, and the fitting clearance of the exhaust system to ensure the service life of the engine and the normal operation of the injector valve stem.
- (3) When installing the injector valve stem on the engine, it is necessary to clean the engine block, cylinder head and other parts connected to the injector valve stem, and ensure that there is no dust, carbon deposits, water, rust spots, etc.
- (4) Before installing, check whether the injector valve stem nozzle gasket has been replaced and installed on the injector valve stem.
- (5) When installing the injector valve stem, apply lubricant between the injector valve stem, fuel nozzle sealing gasket and O-ring.
- (6) Failure to replace the gasket with a new one may result in: deformation of the tight cap of nozzle, deformation of nozzle, deformation of nozzle orifice, oil leakage and air leakage, which will cause serious damage to the injector valve stem and nozzle to break and cause damage to the engine.
- (7) When installing the injector valve stem on the engine, please carefully check the components related to the installation of the injector valve stem, such as the injector valve stem pressure plate, screw, injector valve stem rod and other accessories are not deformed, and install it in strict accordance with the operation steps of the engine maintenance manual.
- (8) It is forbidden to operate the bare injector valve stem for a long time in an environment with serious dust pollution and corrosion to iron products.
- (9) It is forbidden to operate the bare injector valve stem for a long time in a strong magnetic field environment.

2.4. Reasons For 095030-6070 Injector Valve Stem Not Working Normally

- (1) There is air in the oil circuit of the engine fuel system.
- (2) Vehicle oil pump oil supply system is not normal.
- (3) Engine common rail system oil leakage or pressure limiting valve is damaged.
- (4) There is a short circuit, cutting out and poor contact in the wiring harness connected to the injector valve stem of the vehicle.
- (5) The long-term placement of the injector valve stem causes the anti-rust oil to solidify, and the internal components are stuck or the oil holes are blocked.

A Before installing, carefully check whether other components in the common rail system except the injector valve stem are damaged so as to prevent the injector valve stem from not working properly after being replaced.

2.5. Causes of 095030-6070 Injector Valve Stem Being Damaged

- (1) Failure to operate correctly according to the engine maintenance manual during disassembly and assembly resulted in damage to the injector valve stem.
- (2) The fuel used for the vehicle does not meet the standard, causing damage to the injector valve stem, such as: the water content in the fuel oil exceeds the standard, iron powder, aluminum powder,

Mob/Whatsapp: +86 13410541523 Tel: +8675523215133

Email: <u>ruby@shumatt.com</u> Website: <u>www.shumatt.com</u>

sulfide impurities exceed the standard, etc.

- (3) The engine is not regularly maintained according to the engine maintenance manual (please refer to the vehicle maintenance manual for the maintenance mileage). For example, failure to replace the lubricating oil of the engine system for a long time will cause abnormal wear of the engine, excessive exhaust gas volume or a large amount of carbon deposits inside the engine. The filter is not replaced during maintenance or the replaced filter cannot reach the original filter standard. All above reasons can cause damage to the injector valve stem.
- (4) The abrasion of the oil pump produces iron powder and aluminum powder enter the injector valve stem and cause damage to the injector valve stem.
- (5) The deformation and abrasion of fuel tank result in iron powder or aluminum powder entering the injector valve stem and causing damage to the injector valve stem.
- (6) The injector valve stem is damaged due to replacement or adjustment of the relevant parts of the injector valve stem. For example, the valve clearance does not meet the standard after the engine is repaired, the replacement or modification of the wiring harness connected to the injector valve stem fails to meet the original standard.
- (7) The engine is overheated and overloaded for a long time working results in damage to the injector valve stem.
- (8) The injector valve stem will be damaged naturally at the end of its working life.
- (9) The injector valve stem is magnetized (injector valve stem parts' magnetic exceeded) causing the injector valve stem to not work properly.
- ▲ Before replacing the injector valve stem, please check the engine parts carefully according to the engine maintenance manual to avoid the injector valve stem being damaged again after replacement.

2.6. 095030-6070 Injector Valve Stem Storage Standard

(1) Choose a Suitable Storage Place

The warehouse and cargo yard where the injector valve stems are stored should be kept clean and dry, and away from the factory buildings that generate harmful gases and dust; do not mix with acid, alkali, salt and other substances; the storage place should have a good drainage system; the cargo yard should be flattened with gravel or furnace ash etc. to enhance the water permeability of the surface layer to keep the reservoir area dry.

(2) Strict Requirements of Warehousing

Strict inspections should be carried out when the injector valve stems are put into storage, the surface cleaning work should be done well to remove water traces, oil stains, ash and other dirt, remove the rust and do anti-rust treatment in time. Packaged injector valve stems must be protected from damage.

(3) Keep The Warehouse Dry And Preventing Moisture

The relative humidity is usually below 70% for the injector valve stems placed in the room, and the corrosion of the injector valve stems is significantly reduced.

Injector valve stems must be stored in the warehouse, and they are forbidden to store in the same warehouse with commodities with high water content.

(4) Stack Properly

After the injector valve stem is exposed to rain, the corrosion rate will increase significantly. The purpose of sealing is to isolate the injector valve stem from rainwater and humid air, so the warehouse window should be checked in time to avoid rainwater entering the warehouse

Mob/Whatsapp: +86 13410541523 Tel: +8675523215133

Email: ruby@shumatt.com Website: www.shumatt.com



If the injector valve stem package is damaged, it should be repaired or replaced; when the package is damp, the packaging material should be dried; if the original anti-corrosion and oil applied at the factory is found to be damaged or dried up, it should be cleaned and re-applied oil in time.

▲ It is forbidden to leave the injector valve stem exposed in the air for a long time.

▲ It is forbidden to store acid, alkali, salt and other substances together with the injector valve stem.

▲ The unpacked injector valve stem must be rust-proof during secondary storage.

2.7. 095030-6070 Injector Valve Stem Technical Support Obtaining Methods

- (1) Injector Valve Stem Technical File, visit http://shumatt.com to get the technical file.
- (2) Injector Valve Stem Technical Videos

Facebook: Visit https://www.facebook.com/hison.li to get the technical videos, constantly follow can get more information.

YouTube: https://www.youtube.com/channel/UCByvYBx7VjV mAfxh Hu-aw to get the technical videos, constantly follow can get more information.

Shumatt: Visit http://shumatt.com to get the technical videos.

(3) Injector Valve Stem Information Query Software

TruckBook Parts EPC APP, Android/Apple App Store download and install, visit http://shumatt.com to get the download and installation tutorial.

(4) Search the injector valve stem test data through TruckBook Parts EPC APP.

3. 095030-6070 Injector Valve Stem Purchase and Delivery

3.1. 095030-6070 Injector Valve Stem Purchase Payment Term

Payment Terms: T/T, PayPal, Alipay, WeChat

Please contact our salesmen for specific payment information.

3.2. 095030-6070 Injector Valve Stem Main Sales Markets

Injector Valve Stem Main Sales Markets: Asia, Europe, North America, South America, Africa etc.

3.3. 095030-6070 Injector Valve Stem Declaration Requirements

Shumatt can assist customers to provide the following documents for import customs clearance: contract, invoice, packing list, bill of lading, insurance policy, certificate of origin, etc.

3.4. 095030-6070 Injector Valve Stem Shipping Ways

Destination in China Areas: SF Express, Debon Express, the corresponding logistics company can be provided according to customer requirements in special cases.

Destinations Out of China's Areas: DHL, UPS, FedEx, TNT air, ocean or other shipping methods required by customers.

3.5. **095030-6070** Injector Valve Stem Lead time

Lead time: Send out within 3-7 working days after receiving payment (Except for special products and special cases).

Mob/Whatsapp: +86 13410541523 Tel: +8675523215133

Email: ruby@shumatt.com Website: www.shumatt.com



3.6. 095030-6070 Injector Valve Stem Logistics Time for Destination Out of China's Areas

DHL Logistics Time:

50	Country or Region of Departure	Hong Kong, China	Other Countries or Regions of Asia	Australia and New Zealand	Europe	America	Other Countries
	China's Mainland	7 Days	7 Days	8 Days	8 Days	8-12 Days	7-10 Days

UPS Logistics Time: Country or Region of Departure: China's Mainland

Country of Destination	Estimated Arrival Time	Country of Destination	Estimated Arrival Time	Country of Destination	Estimated Arrival Time
Japan	3 Days	UK	5-7Days	Egypt	5-7 Days
Turkey	5-7 Days	Singapore	3 Days	Switzerland	5-7 Days
Bahrain	5-7 Days	Latvia	7-10 Days	New Zealand	7-10 Days
Sri Lanka	5-7 Days	Thailand	3 Days	Austria	5-7 Days
Romania	5-7 Days	Vietnam	3-5 Days	Estonia	5-7 Days
Malaysia	3-5 Days	Israel	5-7 Days	Mexico	7-10 Days
France	5-7 Days	America	5-7 Days	United Arab Emirates	5-7 Days
Italy	5-7 Days	Netherlands	5-7 Days	Bengal	7-10 Days
Lebanon	5-7 Days	Philippine	3-5 Days	Greece	7-10 Days
South Korea	3 Days	Spain	5-7 Days	Myanmar	5-7 Days
Canada	5-7 Days	Germany	5-7 Days	Saudi Arabia	7-10 Days
Portugal	5-7 Days	Australia	5-7 Days	South Africa	7-10 Days
Denmark	5-7 Days	Belgium	5-7 Days	Ukraine	7-10 Days
India	7-10 Days	Qatar	7-10 Days	Poland	5-7 Days
Indonesia	3-5 Days	Morocco	7-10 Days	Pakistan	7-10 Days
Kuwait	7-10 Days	mair!	The state of the s	WELL THE	ATT LAST

lacktriangle The logistics time is for reference only , $\,$ subjects are according to the actual arrival.

3.7. 095030-6070 Injector Valve Stem Packing

Domestic Express Packaging: Usually wrapped in waterproof scotch tape, such as picture No.4.

International Express Packaging: Wrapped with waterproof yellow tape after wrapping the black protective film, such as picture No. 5.

Pallet Shipping: Use fumigation free and recycling trays that meet export requirements, and use white wrapping protective film to wrap and bind with cable ties for the outside, such as picture No. 6, also, the products can be packaged according to customers' requirements.

▲ The packing tray is made of plastic and can be recycled.

▲ Transparent tape, yellow tape, black wrapping protective film, white wrapping protective film are non-degradable materials, please dispose of them properly.

▲ Minors are prohibited from using transparent tape, yellow tape, black wrapping protective film, and white wrapping protective film to avoid personal injury.

Mob/Whatsapp: +86 13410541523 Tel: +8675523215133

Email: ruby@shumatt.com Website: www.shumatt.com



Pic No. 4

Domestic Express Packaging:

Wrapped with transparent tape



Pic No. 5
International Express Packaging:
Wrapped with yellow tape after wrapping black protective film

Website: www.shumatt.com



Pic No. 6

SHUMFIT

Pallet Shipping: Use pallet that meet export requirements, and use white wrapping protective film to wrap and bind with cable ties

Mob/Whatsapp: +86 13410541523 Tel: +8675523215133

EHUMFIT?

Email: ruby@shumatt.com

© 2024 Shenzhen Shumatt Technology Co., Ltd

EHUMFIT!

4. Company Information



Pic No. 7

4.1. Company Introduction

Chinese Name: 深圳市舒马特科技有限公司

English Name: Shenzhen Shumatt Technology Co., Ltd

Injector Valve Stem Manufacturer: Shenzhen Shumatt Technology Co., Ltd

■ Mob Phone/WeChat: +86-13410541523

HK Telephone: +852-67653519

Telephone: +86-755-23215133

Email: ruby@shumatt.com

Website: www.shumatt.com

Shenzhen Office: 11-12, Floor 14, Building 13, Qinchengda Building, Exit A, Honglang North
Subway Station, Bao'an District, Shenzhen, China Mainland

Shenzhen Office: Exit C, Qiao Touxi Metro Station, NO. 66 Chongqing Road, Fuhai Avenue, Bao'an District, Shenzhen, China Mainland

Hong Kong Office: Jianfa Street Industrial Zone, Tuen Mun, New Territories, Hong Kong, China

After-sales Service Address: Please contact our salesmen to obtain and provide the corresponding

Mob/Whatsapp: +86 13410541523 Tel: +8675523215133

Email: ruby@shumatt.com

© 2024 Shenzhen Shumatt Technology Co., Ltd

Website: www.shumatt.com



product maintenance reasons (Reference: 1.9. 095030-6070 Injector Valve Stem Nut Warranty Instructions)

4.2. Sale-men Contact Information

No.	Name	WeChat/WhatsApp	Email	Facebook	YouTube			
1	Ruby	+86-13410541523	ruby@shumatt.com	Hison Li	Hison Li			
2	lvy	+86-18025309821	sales@shumatt.com	Ivy Shumatt	Shumatt IVY			
3	Rebecca	+86-18025349821	sales01@shumatt.com	Rebecca Shumatt	ShumattRebecca			
4	Janny	+86-18028749821	sales02@shumatt.com	Janny shumatt	Janny Shumatt			
5	Sam	+86-13316859821	Sales8@shumatt.com	Shumatt Sam	Sam Shumatt			
6	Natalie	+86-18938945856	sales15@shumatt.com	Shumatt Natalie	Lin Natalie			
7	Ada	+86-1342286353	sales5@shumatt.com	Shumatt Ada	Ada Shumatt			
8	Hison Li	+86-18318811871	web@shumatt.com	Hison Li	Hison Li			
9	Mecca	+86-18938948618	sales11@shumatt.com	Shumatt Mecca	Shumatt Mecca			
10	Eric	+86 18319033618	sales3@shumatt.com	31. 31.	31, 31,			
11	Wayne (Joaquí n enespañol)	+86-13316959821	wayne@shumatt.com	shumattwayne	Wayne Shumatt			
12	Sylvia	+86 18312499884	sales6@shumatt.com	SHOW SHOW	SHOW SHI			
	Visit http://shumatt.com to obtain the latest information of salesmen							
	PS. Shumatt's sales-men's emails are all end with @shumatt.com							

PS: Shumatt's sales-men's emails are all end with @shumatt.com

5. Copyright Statement

The copyright of any contents in this file "095030-6070 Injector Valve Stem G2 Series Technical File" (including but not limited to parameters, data, text, charts, images, sounds, videos, etc.) belongs to Shenzhen Shumatt Technology Co., Ltd. Without the prior written permission of Shenzhen Shumatt Technology Co., Ltd., you are not allowed to modify, duplicate, republish any content in "095030-6070 Injector Valve Stem G2 Series Technical File" in any way. At the same time, any conditions to spread, repost, display the contents of "095030-6070 Injector Valve Stem G2 Series Technical File" should indicate the source of the quoted article, Shenzhen Shumatt Technology Co., Ltd. Any actions failure to follow above conditions violate the "Copyright Law of the People's Republic of China" and other laws and regulations as well as relevant provisions of international conventions.

Mob/Whatsapp: +86 13410541523 Tel: +8675523215133

Email: ruby@shumatt.com Website: www.shumatt.com