

BEBU5A00000 EUP Pump **A5** Series Technical File

SKU1:: Z1WL10001668325

SKU2: Z1K3BEBU5A00000

SKU3: Z1W2EBU5A00000



BEBU5A00000 EUP Pump A5 Series Technical File

Content

1. BEBU5A00000 EUP Pump Introduction	2
1.1. BEBU5A00000 EUP Pump Basic Information	2
1.2. BEBU5A00000 EUP Pump Common Part Number	2
1.3. BEBU5A00000 EUP Pump Parameter	2
1.4. BEBU5A00000 EUP Pump Specifications And Dimensions	2
1.5. BEBU5A00000 EUP Pump Quality Control	2
1.6. BEBU5A00000 EUP Pump Customized Service	3
1.7. BEBU5A00000 EUP Pump Packing List and Package Size	3
1.8. BEBU5A00000 EUP Pump Testing Standard and Certificate	4
1.9. BEBU5A00000 EUP Pump Warranty Instructions	5
1.10. BEBU5A00000 EUP Pump Manufacturer	6
2. BEBU5A00000 EUP Pump Technical Support	6
2.1. BEBU5A00000 EUP Pump Use Location	6
2.2. BEBU5A00000 EUP Pump Installation	7
2.3. BEBU5A00000 EUP Pump Not Working Normally	8
2.4. BEBU5A00000 EUP Pump Causes of Being Damaged	8
2.5. BEBU5A00000 EUP Pump Technical Support Obtaining Methods	9
3. BEBU5A00000 EUP Pump Purchase and Delivery	9
3.1. BEBU5A00000 EUP Pump Purchase Payment Term	9
3.2. BEBU5A00000 EUP Pump Main Sales Markets	9
3.3. BEBU5A00000 EUP Pump Declaration Requirements	9
3.4. BEBU5A00000 EUP Pump Shipping Ways	9
3.5. BEBU5A00000 EUP Pump Lead Time	9
3.6. BEBU5A00000 EUP Pump Logistics Time for Destination Out of China's Areas	10
3.7. BEBU5A00000 EUP Pump Packing	10
4. BEBU5A00000 EUP Pump Storage Standard	11
5. Company Information	12
5.1. Company Introduction	12
	13
5.2. Salesmen's Contact Information	13
SHARKL SHARL SHARLL	
sign,	91 ⁹⁰
SHARK,	98
THE SECTION OF STREET, SHE SHELL,	
aller. Alor,	98
THE	

Mob/Whatsapp: +86 13410541523 Tel: +8675523215133 Website: www.shumatt.com

Email: ruby@shumatt.com

BEBU5A00000 EUP Pump A5 Series Technical File

1. BEBU5A00000 EUP Pump Introduction

1.1. BEBU5A00000 EUP Pump Basic Information

Title	BEBU5A00000 EUP Pump A5 Series	Quality
SKU1	Z1WL10001668325	Re-manufactured
SKU2	Z1K3BEBU5A00000	Re-manufactured
SKU3 ¹	Z1W2EBU5A00000	Re-manufactured

1.2. BEBU5A00000 EUP Pump Common Part Number

(1) EUP Pump Exchange Information

Injector Part Number	ector Part Number OE Number OE Number		OE Number	
BEBU5A00000	1625753	2135456	1668325	

(2) EUP Pump Application Information

Vehicle brand	Car Model	Engine Number
DAF	XF 105	MX 340 S1

(3) EUP Pump Common Writing

BEBU5A00000

1.3. BEBU5A00000 EUP Pump Parameter

Adaptation System: Common Rail System

EUP Pump Series: A5 Series

EUP Pump Type: Diesel EUP pump

1.4. BEBU5A00000 EUP Pump Specifications And Dimensions

EUP Pump Size: 27cm* 11cm *11cm

EUP Pump Net Weight: 1850g EUP Pump Gross Weight: 2050g

EUP Pump Quality: Re-manufactured

EUP Pump Package Size: 29cm* 13cm *13cm

EUP Pump Type: Diesel EUP Pump

EUP Pump MOQ: 4 Pieces

1.5. BEBU5A00000 EUP Pump Quality Control

(1) EUP Pump Testing

All EUP pumps are tested for electrical characteristics, accuracy, high temperature, low temperature, withstand voltage, leakage, durability, and various working conditions.

(2) EUP Pump Assembling

For the quality control of the EUP pump production and installation process, our company strictly follows the standard product installation data and product installation steps to install.

Mob/Whatsapp: +86 13410541523 Tel: +8675523215133

Email: <u>ruby@shumatt.com</u> Website: <u>www.shumatt.com</u>

(3) EUP Pump Inspection

The factory inspection of the EUP pump is undergone full inspection, random inspection, and batch inspection three inspections. Different brands of test benches are used to test the same EUP pump for more than three times for factory inspection, and the EUP pump installation testing environment are progressed in dust-free workshop.

1.6. BEBU5A00000 EUP Pump Customized Service

(1) EUP Pump Customized Service Coverage: Meet the customized needs of OEM manufacturers for shell lettering, logo engraving, EUP pump internal packaging, EUP pump external packaging and labels customized, etc.



(2) EUP Pump Customized Service Requirements:

The quantity of customized EUP pumps shall not be less than 10 pieces.

The quantity of customized EUP pump packages shall not be less than 1000 pieces.

Customized products involve the need of specify logo, the OEM manufacturer needs to provide trademark authorization and the sample of logo image file.

▲ Once the customized EUP pump is sold, it cannot be returned or exchanged if there are no quality problems.

1.7. BEBU5A00000 EUP Pump Packing List and Package Size

(1) EUP Pump Spare Parts List

No.	1	2	3
Stringer, String		Alexander Carrier Carrier	The sales of the sales of
Image			
State State	100000 KT 31	5	311 01 01 01
Name	EUP Pump	Oil Absorbing Paper	VCI Anti-rust Bag
Description	EUP pump part number: BEBU5A00000	Prevent oil leaks	Prevent EUP pumps from rusting
	Tru Tru Tru Tr	120 120 120 120 120 120 120 120 120 120	The The The

Mob/Whatsapp: +86 13410541523 Tel: +8675523215133

Email: <u>ruby@shumatt.com</u> Website: <u>www.shumatt.com</u>



No.	4	5	6
Stray, Stray		Albert Sec. Sec. Albert	Stoley, Strain, Strain, Str.
Image	L. S. L. S.	The same	SHARKLE SHARKLE SHE
	Think the Time to	and and and and	The Thin The
Name	Lining	Injector Packaging Box	30. 30. 1 30. 30.
Description	Prevent the injector from being damaged by external forces	Place the injector and injector accessories	Shippers Shippers Shippers

▲ Minors are prohibited from using the EUP pump assembly, O-rings, EUP pump housing covers, oil return covers, VCI anti-rust bags, and bubble bags to avoid personal injury.

⚠ The EUP pump housing cover and oil return cover are recyclable accessories and can be recycled.

▲ VCI anti-rust bags and bubble bags are non-degradable materials. Please dispose of them properly after use.

⚠ The EUP pump and the installation parts guide tube should be treated with appropriate sealing oil during installation.

(2) EUP Pump Box Size



-	No.	Name	EUP Pump Packing Size (cm)
	1	EUP Pump Packaging Box	29*13*13

1.8. BEBU5A00000 EUP Pump Testing Standard and Certificate

Mob/Whatsapp: +86 13410541523 Tel: +8675523215133

Email: <u>ruby@shumatt.com</u> Website: <u>www.shumatt.com</u>



Shumatt can provide the factory quality inspection test report of each EUP pump to ensure that each EUP pump delivered meets the engine performance indicators.



1.9. BEBU5A00000 EUP Pump Warranty Instructions

(1) Product Warranty Conditions and Instructions

It is necessary to provide pictures, videos, or test reports detected by the EUP pump inspection equipment when the EUP pump is abnormal during use as evidence to feed back to the salesman.

Abnormal conditions are properly explained such as: 1.Smoke, 2. Engine shake, 3. Difficulty starting the

engine, 4. Engine noise, 5. oil leakage etc.

(2) EUP Pump Warranty Coverage

Within 15 days after customer receives the BEBU5A00000 EUP Pump, if there is a performance failure and the product has no appearance damage, customer can choose to replace it or repair it;

If the BEBU5A00000 EUP Pump has performance problems during the warranty period (6-12 months), and it is confirmed that it is product's problems after testing, you can contact our salesmen to replace the same model or a reworked product with the same performance for free;

If the EUP pump house has obvious scratches, it can only be repaired and it will be returned as it is if the product is confirmed to be fault-free.

Tips: For products not covered by warranty, our company can provide paid maintenance services. For products after paid repaired, the same performance problem will have a free warranty period within 3 months from the date of repairing.

(3) EUP Pump Out of Warranty Coverage

Mob/Whatsapp: +86 13410541523 Tel: +8675523215133

Email: <u>ruby@shumatt.com</u> Website: <u>www.shumatt.com</u>



- 1 The warranty period has expired.
- EUP pump failure caused by high temperature, high pressure, humidity, rain and snow, saline-alkali land, earthquake, and used in abnormal environment.
 - 3 Customer disassembles or repairs the EUP pump personally resulting in damage to the EUP pump.
- ④ EUP pump damage caused by man-made reasons (throwing, strong magnetic field magnetization, set fire).
- © EUP pump failure or EUP pump damage caused by non-EUP pump design, technology, manufacturing, quality, and other issues.
- © EUP pump failure due to system pressure exceeding system approved pressure.
 - The EUP pump failure caused by system voltage exceeding approved voltage.
- 8 EUP pump failure caused by impurities (water, lead, aluminum powder, iron powder, sulfide) in the system fuel exceeding the standard requirements.
- (II) EUP pump failure caused by not following the installation angle specified in the vehicle engine maintenance manual.
- 11 EUP pump failure caused by not following the cleaning requirements specified in the vehicle engine maintenance manual.
- 12 EUP pump failure caused by failure to replace consumable parts as specified in the vehicle engine maintenance manual.
- 13 EUP pump failure caused by not complying with the intake system fit clearance and exhaust system fit clearance requirements specified in the vehicle engine maintenance manual.
- 14 Failure to replace the consumable parts and the fitting clearance of the oil inlet system pipeline and the EUP pump connection in accordance with the fuel intake system specified in the vehicle engine maintenance manual.

1.10. BEBU5A00000 EUP Pump Manufacturer

EUP Pump Manufacturer: Shenzhen Shumatt Technology Co., Ltd

2. BEBU5A00000 EUP Pump Technical Support

2.1. BEBU5A00000 EUP Pump Use Location

(1) E.g.: The EUP pump coding is shown below:

Š	No.	Name
	ATT ATT ATT	Nameplate, Logo, Code
6	10 St. 20 St. 20 St.	Story Story, Story, Story, Story, Story, Story, Story, Story,
	and and and and and	T STATE STAT

Mob/Whatsapp: +86 13410541523 Tel: +8675523215133

Email: ruby@shumatt.com Website: www.shumatt.com





2.2. BEBU5A00000 EUP Pump Installation

(1) BEBU5A00000 EUP Pump Installation Precautions:

ho Panlace The Control of the Contro The replacement of the EUP pump must strictly follow the electrical system, the approved pressure of the low-pressure fuel intake system, the approved pressure of the high-pressure fuel circuit system, and fuel system replacement consumables requirements (including the low-pressure fuel circuit system filter and the high-pressure fuel circuit) specified in the vehicle engine maintenance manual.

Replacement of wearing parts of the fuel system, cleaning requirements for the connection between the fuel system and the EUP pump, the fitting clearance of the EUP pump connection, the installation angle and tightening torque of the EUP pump, the fitting clearance of the intake system, and the fitting clearance of the exhaust system to ensure the service life of the engine and the normal operation of the EUP pump.

1300 Mhen installing the EUP pump on the engine, it is necessary to clean the engine block, cylinder head and other parts connected to the EUP pump, and ensure that there is no dust, carbon deposits, water, rust spots, etc.

Tel: +8675523215133 Mob/Whatsapp: +86 13410541523

Email: ruby@shumatt.com Website: www.shumatt.com



A When installing the EUP pump on the engine, please carefully check the components related to the installation of the EUP pump, such as the EUP pump pressure plate, screw, EUP pump rod and other accessories are not deformed, and install it in strict accordance with the operation steps of the engine maintenance manual.

📤 It is forbidden to operate the bare EUP pump for a long time in an environment with serious dust pollution and corrosion to iron products. The The The The The A Property

It is forbidden to operate the bare EUP pump for a long time in a strong magnetic field environment.

2.3. BEBU5A00000 EUP Pump Not Working Normally

"The "The "The This "The

a Tribita a statistica a statistica a statistica

- (1) There is air in the oil circuit of the engine fuel system.
- (2) Vehicle oil pump's oil supply system is not normal.
- (3) Engine common rail system oil leakage or pressure limiting valve damage.

17.7566A75

- (4) There is a short circuit, cutting out and poor contact in the wiring harness connected to the EUP pump of the vehicle.
- (5) The long-term placement of the EUP pump causes the anti-rust oil to solidify, and the internal components are stuck or the oil holes are blocked.

Before installing, carefully check whether other components in the common rail system except the EUP pump are damaged to prevent the EUP pump from not working properly after being replaced.

MINT SHITT SHITT SHITT SHITT SHITT SHITT. 2.4. BEBU5A00000 EUP Pump Causes of Being Damaged (1) Didn't operate are all

- (1) Didn't operate properly according to engine maintenance manual during disassembly or installation, resulting in damage to the EUP pump.
- (2) The fuel oil used for the vehicle does not meet the standard cause damage to the EUP pump, such as: the water content in the fuel oil exceeds the standard, iron powder, aluminum powder, sulfide $\mathcal{Q}_{\mathcal{G}_{\mathcal{G}_{\mathcal{A}}}}$ impurities exceed the standard, etc.
- (3) The engine is not regularly maintained according to the engine maintenance manual (please refer to the vehicle maintenance manual for the maintenance mileage). For example, failure to replace the lubricating oil of the engine system for a long time will cause abnormal wear of the engine, excessive exhaust gas volume or a large amount of carbon deposits inside the engine. The filter is not replaced during maintenance or the replaced filter cannot reach the original filter standard. all above reasons can cause damage to the EUP pump.
- (4) The abrasion of the EUP pump produces iron powder and aluminum powder enter the EUP pump and cause damage to the EUP pump.
- (5) The deformation and abrasion of fuel tank result in iron powder or aluminum powder entering the EUP pump and causing damage to the EUP pump.
- (6) The EUP pump is damaged due to replacement or adjustment of the relevant parts of the EUP pump. For example, the valve clearance does not meet the standard after the engine is repaired, the replacement or modification of the wiring harness connected to the EUP pump fails to meet the original standard.

Mob/Whatsapp: +86 13410541523 Tel: +8675523215133

Email: ruby@shumatt.com Website: www.shumatt.com



- (7) The engine is overheated and overloaded for a long-time working result in damage to the EUP pump.
- (8) The EUP pump will be damaged naturally at the end of its working life.
- (9) The EUP pump is magnetized (EUP pump parts' magnetic exceeded) causing the EUP pump to not work properly.

A Before replacing the EUP pump, please check the engine parts carefully according to the engine maintenance manual to avoid the EUP pump being damaged again after replacement.

2.5. BEBU5A00000 EUP Pump Technical Support Obtaining Methods

- (1) EUP Pump Technical File, visit http://shumatt.com to get the technical file.
- (2) EUP Pump Technical Videos

YouTube: https://www.youtube.com/channel/UCByvYBx7VjV mAfxh Hu-aw to get the technical videos, constantly follow can get more information.

Shumatt: Visit http://shumatt.com to get the technical videos.

(3) EUP Pump Information Query Software

TruckBook Parts EPC APP, Android/Apple App Store download and install, visit http://shumatt.com to get the download and installation tutorial

(4) Search the fuel EUP pump test data through TruckBook Parts EPC APP.

3. BEBU5A00000 EUP Pump Purchase and Delivery

3.1. BEBU5A00000 EUP Pump Purchase Payment Term

Payment Terms: T/T, PayPal, Alipay, WeChat

Δ

Please **c**ontact our salesmen for specific payment information.

3.2. BEBU5A00000 EUP Pump Main Sales Markets

EUP Pump Main Sales Markets: Asia, Europe, North America, South America, Africa etc.

3.3. BEBU5A00000 EUP Pump Declaration Requirements

Shumatt can assist customers to provide the following documents for import customs clearance: contract, invoice, packing list, bill of lading, insurance policy, certificate of origin, etc.

3.4. BEBU5A00000 EUP Pump Shipping Ways

Destination in China Areas: SF Express, Debon Express, the corresponding logistics company can be provided according to customer requirements in special cases.

Destinations Out of China's Areas: DHL, UPS, FedEx, TNT air, ocean or other shipping methods required by customers.

3.5. BEBU5A00000 EUP Pump Lead Time

Lead Time: Send out within 3 – 7 working days after receiving payment (Except for special products and special cases).

Mob/Whatsapp: +86 13410541523 Tel: +8675523215133

Email: ruby@shumatt.com Website: www.shumatt.com

3.6. BEBU5A00000 EUP Pump Logistics Time for Destination Out of China's Areas

DHL Logistics Time:

Country or Region of Departure	Hong Kong, China	Other Countries or Regions of Asia	Australia and New Zealand	Europe	America	Other Countries	ø
China's Mainland	7 Days	7 Days	8 Days	8 Days	8-12 Days	7-10 Days	10

Country of Destination	Estimated Arrival Time	Country of Destination	Estimated Arrival Time	Country of Destination	Estimated Arrival Time
Japan	3 Days	UK	5-7Days	Egypt	5-7 Days
Turkey	5-7 Days	Singapore	3 Days	Switzerland	5-7 Days
Bahrain	5-7 Days	Latvia	7-10 Days	New Zealand	7-10 Days
Sri Lanka	5-7 Days	Thailand	3 Days	Austria	5-7 Days
Romania	5-7 Days	Vietnam	3-5 Days	Estonia	5-7 Days
Malaysia	3-5 Days	Israel	5-7 Days	Mexico	7-10 Days
France	5-7 Days	America	5-7 Days	United Arab Emirates	5-7 Days
Italy	5-7 Days	Netherlands	5-7 Days	Bengal	7-10 Days
Lebanon	5-7 Days	Philippine	3-5 Days	Greece	7-10 Days
South Korea	3 Days	Spain	5-7 Days	Myanmar	5-7 Days
Canada	5-7 Days	Germany	5-7 Days	Saudi Arabia	7-10 Days
Portugal	5-7 Days	Australia	5-7 Days	South Africa	7-10 Days
Denmark	5-7 Days	Belgium	5-7 Days	Ukraine	7-10 Days
India	7-10 Days	Qatar	7-10 Days	Poland	5-7 Days
Indonesia	3-5 Days	Morocco	7-10 Days	Pakistan	7-10 Days
Kuwait	7-10 Days	STATE STATES	THE PROPERTY.		opidis Loopidis

The logistics time is for reference only and is subject to the actual arrival.

3.7. BEBU5A00000 EUP Pump Packing

Domestic Express Packaging: Usually wrapped in waterproof scotch tape, such as picture No. 1.

International Express Packaging: Wrapped with waterproof yellow tape After wrapping the black protective film, such as picture No. 2.

Pallet Shipping: Use fumigation free and recycling trays that meet export requirements, and use white wrapping protective film to wrap and bind with cable ties for the outside, such as picture No. 3, also, the products can be packaged according to customers' requirements.

MATE A MATE A MATE AND MATE AND MATE AND MATERIAL The packing tray is made of plastic and can be recycled.

Mob/Whatsapp: +86 13410541523 Tel: +8675523215133

THE THE THE THE THE THE THE THE THE

Email: ruby@shumatt.com Website: www.shumatt.com



Transparent tape, yellow tape, black wrapping protective film, white wrapping protective film are non-degradable materials, please dispose of them properly.

Minors are prohibited from using transparent tape, yellow tape, black wrapping protective film, and white wrapping protective film to avoid personal injury.



Domestic express packaging:
Wrapped with Transparent tape

Pic No. 1



International express packaging:
Wrapped with yellow tape after wrapping black protective film



Pic No. 3

Pallet shipment: Use pallets that meet export requirements and wrap with white plastic wrap and tie.

4. BEBU5A00000 EUP Pump Storage Standard

(1) Choose a Suitable Storage Place

The warehouse and cargo yard where the EUP pump is stored should be kept clean and dry, and away from the factory buildings that generate harmful gases and dust; do not mix with acids, alkali, salt, and other substances; the storage place should have a good drainage system; the cargo yard should be flattened with gravel or furnace ash etc. to enhance the water permeability of the surface layer to keep the reservoir area dry.

(2) Strict Requirements of Warehousing

eal Se

Strict inspections should be carried out when the EUP pumps are put into storage, the surface cleaning work should be done well to remove water traces, oil stains, ashes, and other dirt, remove the rust and do anti-rust treatment in time. Packaged EUP pumps must be protected from damage.

Mob/Whatsapp: +86 13410541523 Tel: +8675523215133

Email: <u>ruby@shumatt.com</u> Website: <u>www.shumatt.com</u>

(3) Keep The Warehouse Dry And Preventing Moisture

The relative humidity is usually below 70% for the EUP pumps placed in the room, and the corrosion of a Tillian Tillian the EUP pumps is significantly reduced.

EUP pumps must be stored in the warehouse, and they are forbidden to store in the same warehouse with commodities with high water content.

(4) Stack Properly

After the EUP pump is exposed to rain, the corrosion rate will increase significantly. The purpose of sealing is to isolate the EUP pump from rainwater and humid air, so the warehouse window should be checked in time to avoid rainwater entering the warehouse.

If the EUP pump package is damaged, it should be repaired or replaced; when the package is damp, the packaging material should be dried; if the original anti-corrosion and oil applied at the factory is found to be damaged or dried up, it should be cleaned and re-applied oil in time.

It is forbidden to leave the EUP pump exposed in the air for a long time.

It is forbidden to store acids, alkalis, salts, and other substances together with the EUP pump.

The unpacked EUP pump must be rust-proof during secondary storage.

5. Company Information



5.1. Company Introduction

Chinese Name: 深圳市舒马特科技有限公司

English Name: Shenzhen Shumatt Technology Co., Ltd

Mob Phone/WeChat: +86-13410541523

Mob/Whatsapp: +86 13410541523

Email: ruby@shumatt.com

© 2025 Shenzhen Shumatt Technology Co., Ltd

Tel: +8675523215133

Website: www.shumatt.com



HK Telephone: +852-67653519

Telephone: +86-755-23215133

Email: ruby@shumatt.com

Website: www.shumatt.com

Shenzhen Office: 11-12, Floor 14, Building 13, Qinchengda Building, Exit A, Honglang North Subway Station, Bao'an District, Shenzhen, China's Mainland

Shenzhen Office: Exit C, Qiao Touxi Metro Station, NO. 66 Chongqing Road, Fuhai Avenue, Bao'an District, Shenzhen, China Mainland

Hong Kong Office: Jianfa Street Industrial Zone, Tuen Mun, New Territories, Hong Kong, China

After-sales Service Address: Please contact our salesmen to obtain and provide the corresponding product maintenance reasons (Reference: 1.9. BEBU5A00000 EUP Pump Warranty Instructions)

5.2. Salesmen's Contact Information

No.	Name	WeChat/WhatsApp	Email
1,00	Ruby	+86-13410541523	ruby@shumatt.com
2	Strange Strang	+86-18025299821	sales@shumatt.com
3	Rebecca	+86-18025349821	sales01@shumatt.com
4	Janny	+86-18028749821	sales02@shumatt.com
5	Sam	+86-13316859821	Sales8@shumatt.com
6	Natalie	+86- 18938945856	sales15@shumatt.com
7	Ada	+86-1342286353	sales5@shumatt.com
8	Hison Li	+86-18318811871	web@shumatt.com
9	Mecca	+86-18938948618	sales11@shumatt.com
10	Eric	+86 18319033618	sales3@shumatt.com
11	Wayne (Joaquín en español)	+86-13316959821	wayne@shumatt.com
12	Sylvia	+86 18312499884	sales6@shumatt.com
NOTES	Visit http://shumatt.com	to obtain the latest informat	ion of salesmen

6. Copyright Statement

The copyright of any contents (including but not limited to parameters, data, text, charts, images, sounds, or videos, etc.) provided in "BEBU5A00000 EUP Pump A5 Series Technical File" belong to Shenzhen Shumatt Technology Co., Ltd. Without the prior written permission of Shenzhen Shumatt Technology Co., Ltd., you are not allowed to modify any contents in "BEBU5A00000 EUP Pump A5 Series Technical File" in


PS: Shumatt's salesmen's emails are all end with @shumatt.com

Mob/Whatsapp: +86 13410541523 Tel: +8675523215133

Email: <u>ruby@shumatt.com</u> Website: <u>www.shumatt.com</u>



any way. At the same time, any conditions to spread, repost, display the contents of "BEBU5A00000 EUP Pump A5 Series Technical File" should indicate that the cited article is from Shenzhen Shumatt Technology Co., Ltd., Any actions failure to follow above conditions to use "BEBU5A00000 EUP Pump A5 Series Technical File" will violate the "Copyright Law of the People's Republic of China" and other laws and regulations and the provisions of relevant international conventions.



Mob/Whatsapp: +86 13410541523

Email: ruby@shumatt.com

© 2025 Shenzhen Shumatt Technology Co., Ltd

Tel: +8675523215133

Website: www.shumatt.com