

F00RJ00222 Injector Solenoid Valve O-ring Technical File

SKU: G1L2F00RJ00222





F00RJ00222 injector solenoid valve O-ring Technical File

1. F00RJ00222 Injector Solenoid Valve O-ring Introduction	2
1.1. F00RJ00222 Injector Solenoid Valve O-ring Basic Information	2
1.2. F00RJ00222 Injector Solenoid Valve O-ring Common Part Number	2
1.3. F00RJ00222 Injector Solenoid Valve O-ring Parameter	3
1.4. F00RJ00222 Injector Solenoid Valve O-ring Specifications And Dimensions	3
1.5.F00RJ00222 Injector Solenoid Valve O-ring Quality Control	3
1.6.F00RJ00222 Injector Solenoid Valve O-ring Customized Service	4
1.7.F00RJ00222 Injector Solenoid Valve O-ring Packing List and Package Size	4
1.8.F00RJ00222 Injector Solenoid Valve O-ring Testing Standard and Certificate	6
1.9.F00RJ00222 Injector Solenoid Valve O-ring Warranty Instructions	6
1.10.F00RJ00222 Injector Solenoid Valve O-ring Manufacturer	7
2.F00RJ00222 Injector Solenoid Valve O-ring Technical Support	7
2.1.F00RJ00222 Injector Solenoid Valve O-ring Usage Location	7
2.2.F00RJ00222 Injector Solenoid Valve O-ring Installation	8
2.3.F00RJ00222 Injector Solenoid Valve O-ring Reasons for Not Working Normally	9
2.4.F00RJ00222 Injector Solenoid Valve O-ring Causes of Being Damaged	9
2.5.F00RJ00222 Injector Solenoid Valve O-ring Technical Support Obtaining Methods	.10
3.F00RJ00222 Injector Solenoid Valve O-ring Purchase and Delivery	.10
3.1.F00RJ00222 Injector Solenoid Valve O-ring Purchase Payment Term	.10
3.2.F00RJ00222 Injector Solenoid Valve O-ring Main Sales Markets	.10
3.3.F00RJ00222 Injector Solenoid Valve O-ring Declaration Requirements	.10
	.10
3.5.F00RJ00222 Injector Solenoid Valve O-ring Lead time	.11
3.6.F00RJ00222 Injector Solenoid Valve O-ring Logistics Time for Destination Out of China's Areas	.11
3.7.F00RJ00222 Injector Solenoid Valve O-ring Packing	.11
4.F00RJ00222 Injector Solenoid Valve O-ring Storage Standard	.12
5. Company Information	.13
5.1.Company Introduction	.14
5.2.Sales-men's Contact Information	
6.Copyright Statement	.15
SATISAL	e)(³⁾
SHIRKLE	
Stephen Stephen, Step	98
SANDALL	51 ⁽⁵⁾
THE THE PERSON WITH A PERSON THE	

Mob/Whatsapp: +86 13410541523 Tel: +8675523215133

Email: ruby@shumatt.com Website: www.shumatt.com



F00RJ00222 Injector Solenoid Valve O-ring Technical File

1. F00RJ00222 Injector Solenoid Valve O-ring Introduction

1.1. F00RJ00222 Injector Solenoid Valve O-ring Basic Information

Title	F00RJ00222 Injector Solenoid Valve O-ring	Quality
SKU	G1L2F00RJ00222	China Made New

1.2. F00RJ00222 Injector Solenoid Valve O-ring Common Part Number (1) Injector Solenoid Valve O

(1) Injector Solenoid Valve O-ring Applicacable Injector Model

Injector Part Number	Injector Part Number	Injector Part Number	Injector Part Number	Injector Part Number
0445120024	0445120027	0445120030	0445120053	0445120054
0445120055	0445120056	0445120057	0445120061	0445120062
0445120063	0445120064	0445120065	0445120066	0445120067
0445120068	0445120071	0445120074	0445120075	0445120078
0445120080	0445120081	0445120082	0445120083	0445120086
0445120087	0445120092	0445120098	0445120099	0445120100
0445120101	0445120102	0445120105	0445120107	0445120110
0445120116	0445120117	0445120118	0445120124	0445120127
0445120128	0445120129	0445120130	0445120131	0445120134
0445120135	0445120136	0445120137	0445120138	0445120139
0445120141	0445120142	0445120143	0445120145	0445120146
0445120147	0445120148	0445120149	0445120150	0445120153
0445120154	0445120155	0445120156	0445120157	0445120160
0445120161	0445120162	0445120163	0445120164	0445120167
0445120168	0445120169	0445120170	0445120177	0445120178
0445120179	0445120180	0445120182	0445120183	0445120184
0445120185	0445120186	0445120187	0445120188	0445120191
0445120192	0445120193	0445120196	0445120197	0445120199

Mob/Whatsapp: +86 13410541523 Tel: +8675523215133

Email: ruby@shumatt.com Website: www.shumatt.com



0445120200	0445120201	0445120202	04451202203	0445120204
0445120213	0445120214	0445120215	0445120217	0445120218
0445120219	0445120220	0445120222	0445120224	0445120225
0445120226	0445120227	0445120228	0445120229	0445120232
0445120233	0445120234	0445120235	0445120242	0445120244

(2) Injector Solenoid Valve O-ring Matching Information

Car Model	Engine Number	OE Number		
Silverado 3500 6.6	CLY STEELS	ti, sti, sti, sti		
580 SN	445TA	2855 491		
160 Midlum II	DXi 5 160	74 21 006 073		
J6 12.4 D	CA6DN1	THE THE THE THE		
V7 5.2 D	YC4G180-30	G1000-1112100-A38		

(3) Injector Solenoid Valve O-ring Part Number Common Writing

F00RJ00222, F 00R J00 222, F00 RJ0 0222, F00RJ00 222, F00 RJ00222, F 00RJ00222

1.3. F00RJ00222 Injector Solenoid Valve O-ring Parameter

Adaptation System: Common Rail System

Injector Solenoid Valve O-ring Series: 120 Series
Injector Solenoid Valve O-ring Type: Electromagnetic

1.4. F00RJ00222 Injector Solenoid Valve O-ring Specifications And Dimensions

Injector Solenoid Valve O-ring Size: Outer diameter: 28.5mm Inner diameter: 22.9mm Diameter: 2.8mm

Injector Solenoid Valve O-ring Net Weight: 8g
Injector Solenoid Valve O-ring Gross Weight: 50g
Injector Solenoid Valve O-ring Quality: China Made New
Injector Solenoid Valve O-ring Package Size: 11cm* 10cm *3cm

Injector Solenoid Valve O-ring Type: High Pressure Common Rail Injector Solenoid Valve O-ring

Injector Solenoid Valve O-ring MOQ: 100pcs

1.5.F00RJ00222 Injector Solenoid Valve O-ring Quality Control

(1) Injector Solenoid Valve O-ring Testing

All injector solenoid valve O-ring spare parts are tested for electrical characteristics, accuracy, high temperature, low temperature, withstand voltage, leakage, durability, and various working conditions.

(2) Injector Solenoid Valve O-ring Assembling

For the quality control of the injector solenoid valve O-ring production and installation process, our company strictly follows the standard product installation data and product installation steps to install, such

Mob/Whatsapp: +86 13410541523 Tel: +8675523215133

Email: ruby@shumatt.com Website: www.shumatt.com

as injector solenoid valve O-ring stroke test, injector solenoid valve O-ring solenoid valve tightening torque, injector solenoid valve O-ring nozzle tightening torque.

(3) Injector Solenoid Valve O-ring Inspection

The factory inspection of the injector solenoid valve O-ring is undergone full inspection, random inspection, and batch inspection three inspections. Different brands of test benches are used to test the same injector solenoid valve O-ring for more than three times for factory inspection, and the injector solenoid valve O-ring installation testing environment are progressed in dust-free workshop.

1.6.F00RJ00222 Injector Solenoid Valve O-ring Customized Service

(1) Injector Solenoid Valve O-ring Customized Service Coverage: Meet the customized needs of OEM manufacturers for shell lettering, logo engraving, injector solenoid valve O-ring internal packaging, injector solenoid valve O-ring external packaging and labels customized, etc.



(2) Injector Solenoid Valve O-ring Customized Service Requirements:

The quantity of customized injector solenoid valve O-rings shall not be less than 10 pieces.

The quantity of customized injector solenoid valve O-ring packages shall not be less than 1000 pieces.

Customized products involve the need of specify logo, the OEM manufacturer needs to provide trademark authorization and the sample of logo image file.

• Once the customized injector solenoid valve O-ring is sold, it cannot be returned or exchanged if there is no quality problem.

1.7.F00RJ00222 Injector Solenoid Valve O-ring Packing List and Package Size

(1) Injector Solenoid Valve O-ring Parts List

No.	1	2	3
SHADALLI	Shumatt Shumatt	Shumatt : 55450000	Shumatt 57
Image	ALL SALES	HAMMALL SAS	**************************************
Name	Injector solenoid valve O- ring assy	Body O-ring diameter size	Body O-ring inner diameter
Description	The The The The The	Diameter: 1.4mm	Inner diameter: 24.7mm
No.	4		

Mob/Whatsapp: +86 13410541523 Tel: +8675523215133

Email: ruby@shumatt.com Website: www.shumatt.com



Shamer Share	<i>₹</i> 1	/	/
Name	Body O-ring outer diameter	Dr. Dr. Vo. Dr.	
Description	Outer diameter: 27.5mm		

Minors are forbidden to use the injector solenoid valve O-ring assembly, O-ring, nozzle protective cover, fuel injector solenoid valve O-ring housing protective cover, oil return protective cover, VCI antirust bag, and air bubble bag to avoid personal injury.

• O-ring and nozzle gasket are disposable installation accessories, and need to be replaced for re-installation.

The nozzle protective cover, the injector solenoid valve O-ring housing protective cover, and the oil return protective cover are recyclable accessories and can be recycled.

A VCI anti-rust bags and bubble bags are non-degradable materials, please dispose them properly after using.

The injector solenoid valve O-ring and the installation parts should be coated with appropriate sealing oil during installation.

(2) Injector Solenoid Valve O-ring Package Size



Mob/Whatsapp: +86 13410541523 Tel: +8675523215133

Email: ruby@shumatt.com Website: www.shumatt.com



, No	Э.	Name	Injector Solenoid Valve O-ring Package Size (cm)
1		Injector Solenoid Valve O-ring Package	11*10*3

1.8.F00RJ00222 Injector Solenoid Valve O-ring Testing Standard and Certificate

Shumatt can provide the factory quality inspection test report of each injector solenoid valve O-ring to ensure that each delivered injector solenoid valve O-ring meets the engine performance indicators.



1.9.F00RJ00222 Injector Solenoid Valve O-ring Warranty Instructions

(1) Product Warranty Conditions and Instructions

It is necessary to provide pictures, videos, or test reports detected by the injector solenoid valve O-ring inspection equipment when the injector solenoid valve O-ring is abnormal during use as evidence to feed back to the salesman.

Abnormal conditions are properly explained such as: 1.Smoke, 2. Engine shake, 3. Difficulty starting the engine, 4. Engine noise, 5. oil leakage etc.

(2) Injector Solenoid Valve O-ring Warranty Coverage

Within 15 days after customer receives the F00RJ00222 injector solenoid valve O-ring, if there is a performance failure and the product has no appearance damage, customer can choose to replace it or repair it;

If the F00RJ00222 injector solenoid valve O-ring has performance problems during the warranty period (6-12 months), and it is confirmed that it is product's problems after testing, you can contact our salesmen to replace the same model or a reworked product with the same performance for free;

If the injector solenoid valve O-ring house has obvious scratches, it can only be repaired and it will be returned as it is if the product is confirmed to be fault-free.

Mob/Whatsapp: +86 13410541523 Tel: +8675523215133

Email: ruby@shumatt.com Website: www.shumatt.com



⚠ Tips: For products not covered by warranty, our company can provide paid maintenance services. For products after paid repaired, the same performance problem will have a free warranty period within 3 months from the date of repairing.

(3) Injector Solenoid Valve O-ring Out of Warranty Coverage

- 1 The warranty period has expired.
- ② Injector solenoid valve O-ring failure caused by high temperature, high pressure, humidity, rain and snow, saline-alkali land, earthquake, and used in abnormal environment.
- 3 Customer disassembles or repairs the injector solenoid valve O-ring personally resulting in damage to the injector solenoid valve O-ring.
- 4 Injector solenoid valve O-ring damage caused by man-made reasons (throwing, strong magnetic field magnetization, set fire).
- ⑤ Injector solenoid valve O-ring failure or injector solenoid valve O-ring damage caused by non-injector solenoid valve O-ring design, technology, manufacturing, quality, and other issues.
- 6 Injector solenoid valve O-ring failure due to system pressure exceeding system approved pressure.
 - ① Injector solenoid valve O-ring failure caused by system voltage exceeding approved voltage.
- ® Injector solenoid valve O-ring failure caused by impurities (water, lead, aluminum powder, iron powder, sulfide) in the system fuel exceeding the standard requirements.
- 9 Injector solenoid valve O-ring failure caused by not installing according to the tightening torque specified in the vehicle engine maintenance manual (the tightening torque is too large or too small).
- Injector Solenoid valve O-ring failure caused by not following the installation angle specified in the vehicle engine maintenance manual.
- 11 Injector solenoid valve O-ring failure caused by not following the cleaning requirements specified in the vehicle engine maintenance manual.
- 12 Injector solenoid valve O-ring failure caused by failure to replace consumable parts as specified in the vehicle engine maintenance manual.
- 13 Injector solenoid valve O-ring failure caused by not complying with the intake system fit clearance and exhaust system fit clearance requirements specified in the vehicle engine maintenance manual.
- 14 Failure to replace the consumable parts and the fitting clearance of the oil inlet system pipeline and the injector solenoid valve O-ring connection in accordance with the fuel intake system specified in the vehicle engine maintenance manual.

1.10.F00RJ00222 Injector Solenoid Valve O-ring Manufacturer

Injector Solenoid Valve O-ring's Manufacturer: Shenzhen Shumatt Technology Co., Ltd

2.F00RJ00222 Injector Solenoid Valve O-ring Technical Support

2.1.F00RJ00222 Injector Solenoid Valve O-ring Usage Location

(1) E.g.: See the injector solenoid valve O-ring location as follows

No.	Name
Α	Injector Solenoid Valve O-ring

Mob/Whatsapp: +86 13410541523 Tel: +8675523215133

Email: ruby@shumatt.com Website: www.shumatt.com

© 2025 Shenzhen Shumatt Technology Co., Ltd

400





2.2.F00RJ00222 Injector Solenoid Valve O-ring Installation

(1) F00RJ00222 Injector Solenoid Valve O-ring Installation Precautions:

The replacement of the injector solenoid valve O-ring must strictly follow the electrical system, the approved pressure of the low-pressure fuel intake system, the approved pressure of the high-pressure fuel circuit system, and fuel system replacement consumables requirements (including the low-pressure fuel circuit system filter and the high-pressure fuel circuit) specified in the vehicle engine maintenance manual.

A Strictly follow the operation manual of replacement of wearing parts of the fuel system, cleaning requirements for the connection between the fuel system and the injector solenoid valve O-ring, the fitting clearance of the injector solenoid valve O-ring connection, the installation angle and tightening torque of the injector solenoid valve O-ring, the fitting clearance of the intake system, and the fitting clearance of the exhaust system, so that to ensure the service life of the engine and the normal operation of the injector solenoid valve O-ring.

When installing the injector solenoid valve O-ring on the engine, it is necessary to clean the engine block, cylinder head and other parts connected to the injector solenoid valve O-ring, and ensure that there is no dust, carbon deposits, water, rust spots, etc.

A Before installing, check whether the injector solenoid valve O-ring nozzle gasket has been replaced and installed on the injector solenoid valve O-ring.

⚠ When installing the injector solenoid valve O-ring, apply lubricant between the injector solenoid valve O-ring, injector solenoid valve O-ring nozzle sealing gasket and O-ring.

If a new gasket is not replaced, it can lead to: deformation of the tight cap of nozzle, deformation of nozzle, deformation of nozzle orifice, oil leakage and air leakage, which will cause serious damage to the injector solenoid valve O-ring and nozzle to break and cause damage to the engine.

Mob/Whatsapp: +86 13410541523 Tel: +8675523215133

Email: ruby@shumatt.com Website: www.shumatt.com



When installing the injector solenoid valve O-ring on the engine, please carefully check the components related to the installation of the injector solenoid valve O-ring to ensure they are not deformed, such as the injector solenoid valve O-ring pressure plate, screw, injector solenoid valve O-ring rod and other accessories, and install it in strict accordance with the operation steps of the engine maintenance manual.

⚠ It is forbidden to operate the bare injector solenoid valve O-ring for a long-time in an environment with serious dust pollution and corrosion to iron products.

▲ It is forbidden to operate the bare injector solenoid valve O-ring for a long time in a strong magnetic field environment.

2.3.F00RJ00222 Injector Solenoid Valve O-ring Reasons for Not Working Normally

(1) There is air in the oil circuit of the engine fuel system.

MELL "MELL "MELL "MELL "MELL

- (2) Vehicle fuel injector solenoid valve O-ring fuel supply system is abnormal.
- (3) Engine common rail system oil leakage or pressure limiting valve damage.
- (4) There is a short circuit, cutting out and poor contact in the wiring harness connected to the injector solenoid valve O-ring of the vehicle.
- (5) The long-term placement of the injector solenoid valve O-ring causes the anti-rust oil to solidify, and the internal components are stuck or the oil holes are blocked.

A Before installing, carefully check whether other components in the common rail system except the injector solenoid valve O-ring are damaged to prevent the injector solenoid valve O-ring from not working properly after being replaced.

2.4.F00RJ00222 Injector Solenoid Valve O-ring Causes of Being Damaged

(1) Didn't operate properly according to engine maintenance manual during disassembly or installation, resulting in damage to the injector solenoid valve O-ring.

water water.

- (2) The fuel oil used for the vehicle does not meet the standard cause damage to the injector solenoid valve O-ring, such as: the water content in the fuel oil exceeds the standard, iron powder, aluminum powder, sulfide impurities exceed the standard, etc.
- (3) The engine is not regularly maintained according to the engine maintenance manual (please refer to the vehicle maintenance manual for the maintenance mileage). For example, failure to replace the lubricating oil of the engine system for a long time will cause abnormal wear of the engine, excessive exhaust gas volume or a large amount of carbon deposits inside the engine. The filter is not replaced during maintenance or the replaced filter cannot reach the original filter standard. all above reasons can cause damage to the injector solenoid valve O-ring.
- (4) The abrasion of the injector solenoid valve O-ring produces iron powder and aluminum powder enter the injector solenoid valve O-ring and cause damage to the injector solenoid valve O-ring.
- (5) The deformation and abrasion of fuel tank result in iron powder or aluminum powder entering the injector solenoid valve O-ring and causing damage to the injector solenoid valve O-ring.
- (6) The injector solenoid valve O-ring is damaged due to replacement or adjustment of the relevant parts of the injector solenoid valve O-ring. For example, the valve clearance does not meet the standard

Mob/Whatsapp: +86 13410541523 Tel: +8675523215133

Email: ruby@shumatt.com Website: www.shumatt.com



after the engine is repaired, the replacement or modification of the wiring harness connected to the injector solenoid valve O-ring fails to meet the original standard.

- (7) The engine is overheated and overloaded for a long-time working result in damage to the injector solenoid valve O-ring.
- (8) The injector solenoid valve O-ring will be damaged naturally at the end of its working life.
- (9) The injector solenoid valve O-ring is magnetized (injector solenoid valve O-ring parts' magnetic exceeded) causing the injector solenoid valve O-ring to not work properly.

A Before replacing the injector solenoid valve O-ring, please check the engine parts carefully according to the engine maintenance manual to avoid the injector solenoid valve O-ring being damaged again after replacement.

2.5.F00RJ00222 Injector Solenoid Valve O-ring Technical Support Obtaining Methods

- (1) Injector Solenoid Valve O-ring Technical File, visit http://shumatt.com to get the technical file.
- (2) Injector Solenoid Valve O-ring Technical Videos

Facebook: Visit https://www.facebook.com/hison.li to get the technical videos, constantly follow can get more information.

YouTube: https://www.youtube.com/channel/UCByvYBx7VjV_mAfxh_Hu-aw_to get the technical videos, constantly follow can get more information.

Shumatt: Visit http://shumatt.com to get the technical videos.

(3) Injector Solenoid Valve O-ring Information Query Software

TruckBook Parts EPC APP, Android/Apple App Store download and install, visit http://shumatt.com to get the download and installation tutorial

(4) Search The injector solenoid valve O-ring test data through TruckBook Parts EPC APP.

3.F00RJ00222 Injector Solenoid Valve O-ring Purchase and Delivery

3.1.F00RJ00222 Injector Solenoid Valve O-ring Purchase Payment Term

Payment Terms: T/T, PayPal, Alipay, WeChat

Please contact our salesmen for specific payment information.

3.2.F00RJ00222 Injector Solenoid Valve O-ring Main Sales Markets

Injector Solenoid Valve O-ring main sales markets: Asia, Europe, North America, South America, Africa etc.

3.3.F00RJ00222 Injector Solenoid Valve O-ring Declaration Requirements

Shumatt can assist customers to provide the following documents for import customs clearance: contract, invoice, packing list, bill of lading, insurance policy, certificate of origin, etc.

3.4.F00RJ00222 Injector Solenoid Valve O-ring Shipping Ways

Destination in China Areas: SF Express, Debon Express, the corresponding logistics company can be provided according to customer requirements in special cases.

Destinations Out of China's Areas: DHL, UPS, FedEx, TNT air, ocean or other shipping methods required by customers.

Mob/Whatsapp: +86 13410541523 Tel: +8675523215133

Email: ruby@shumatt.com Website: www.shumatt.com

© 2025 Shenzhen Shumatt Technology Co., Ltd

10 / 14



3.5.F00RJ00222 Injector Solenoid Valve O-ring Lead time

Lead time: Send out within 3 – 7 working days after receiving payment (Except for special products and

3.6.F00RJ00222 Injector Solenoid Valve O-ring Logistics Time for Destination Out of China's Areas DHL Logistics Time:

Country or Region of Departure	Hong Kong, China	Other Countries or Regions of Asia	Australia and New Zealand	Europe	America	Other Countries
China's Mainland	7 Days	7 Days	8 Days	8 Days	8-12 Days	7-10 Days

UPS Logistics Time: Country or Region of Departure: China's Mainland

Country of Destination	Estimated Arrival Time	Country of Destination	Estimated Arrival Time	Country of Destination	Estimated Arrival Time
Japan	3 Days	ATT TOK	5-7Days	Egypt	5-7 Days
Turkey	5-7 Days	Singapore	3 Days	Switzerland	5-7 Days
Bahrain	5-7 Days	Latvia	7-10 Days	New Zealand	7-10 Days
Sri Lanka	5-7 Days	Thailand	3 Days	Austria	5-7 Days
Romania	5-7 Days	Vietnam	3-5 Days	Estonia	5-7 Days
Malaysia	3-5 Days	Israel	5-7 Days	Mexico	7-10 Days
France	5-7 Days	America	5-7 Days	United Arab Emirates	5-7 Days
Italy	5-7 Days	Netherlands	5-7 Days	Bengal	7-10 Days
Lebanon	5-7 Days	Philippine	3-5 Days	Greece	7-10 Days
South Korea	3 Days	Spain	5-7 Days	Myanmar	5-7 Days
Canada	5-7 Days	Germany	5-7 Days	Saudi Arabia	7-10 Days
Portugal	5-7 Days	Australia	5-7 Days	South Africa	7-10 Days
Denmark	5-7 Days	Belgium	5-7 Days	Ukraine	7-10 Days
India	7-10 Days	Qatar	7-10 Days	Poland	5-7 Days
Indonesia	3-5 Days	Morocco	7-10 Days	Pakistan	7-10 Days
Kuwait	7-10 Days	States I States St	nega, Fingley	-18 18 18 18 18 18 18 18 18 18 18 18 18 1	Stable S

The logistics time is for reference only and is subject to the actual arrival.

- St. 1975

80,000

3.7.F00RJ00222 Injector Solenoid Valve O-ring Packing

985

2000

Domestic express packaging: Usually wrapped in waterproof scotch tape, such as picture No.1.

International express packaging: Wrapped with waterproof yellow tape After wrapping the black protective film, such as picture No. 2. 4000

Pallet Shipping: Use fumigation free and recycling trays that meet export requirements, and use white wrapping protective film to wrap and bind with cable ties for the outside, such as picture No. 3,

Mob/Whatsapp: +86 13410541523 Tel: +8675523215133

Email: ruby@shumatt.com Website: www.shumatt.com

also, the products can be packaged according to customers' requirements.

The packing tray is made of plastic and can be recycled.

Transparent tape, yellow tape, black wrapping protective film, white wrapping protective film are non-degradable materials, please dispose of them properly.

Minors are prohibited from using transparent tape, yellow tape, black wrapping protective film, and white wrapping protective film to avoid personal injury.



Pic No. 1 Domestic express packaging: Wrapped with Transparent tape



International express packaging: Wrapped with yellow tape after wrapping black protective film



Pic No. 3

Pallet Shipping: Use pallet that meet export requirements, and use white wrapping protective film to wrap and bind with cable ties

4.F00RJ00222 Injector Solenoid Valve O-ring Storage Standard

(1) Choose a suitable storage place

WALL SHOUL SHOUL SHOUL

The warehouse and cargo yard where the injector solenoid valve O-ring is stored should be kept clean and dry, and away from the factory buildings that generate harmful gases and dust; do not mix with acids, alkali, salt and other substances; the storage place should have a good drainage system; the cargo yard

Mob/Whatsapp: +86 13410541523 Tel: +8675523215133

Email: ruby@shumatt.com Website: www.shumatt.com



should be flattened with gravel or furnace ash etc. to enhance the water permeability of the surface layer to keep the reservoir area dry.

(2) Strict requirements of warehousing

Strict inspections should be carried out when the injector solenoid valve O-rings are put into storage, the surface cleaning work should be done well to remove water traces, oil stains, ash, and other dirt, remove the rust and do anti-rust treatment in time. Packaged injector solenoid valve O-rings must be protected from damage.

(3) Keep the warehouse dry and preventing moisture

The relative humidity is usually below 70% for the injector solenoid valve O-rings placed in the room, and the corrosion of the injector solenoid valve O-rings is significantly reduced.

Injector Solenoid Valve O-rings must be stored in the warehouse, and they are forbidden to store in the same warehouse with commodities with high water content.

(4) Stack Properly

After the injector solenoid valve O-ring is exposed to rain, the corrosion rate will increase significantly. The purpose of sealing is to isolate the injector solenoid valve O-ring from rainwater and humid air, so the warehouse window should be checked in time to avoid rainwater entering the warehouse

If the injector solenoid valve O-ring package is damaged, it should be repaired or replaced; when the package is damp, the packaging material should be dried; if the original anti-corrosion and oil applied at the factory is found to be damaged or dried up, it should be cleaned and re-applied oil in time.



It is forbidden to leave the injector solenoid valve O-ring exposed in the air for a long time.

It is forbidden to store acids, alkali, salt, and other substances together with the injector solenoid Valve O-ring.



The unpacked injector solenoid valve O-ring must be rust-proof during secondary storage.

5. Company Information

Mob/Whatsapp: +86 13410541523 Tel: +8675523215133

Email: ruby@shumatt.com Website: www.shumatt.com

© 2025 Shenzhen Shumatt Technology Co., Ltd

13 / 14





5.1.Company Introduction

Chinese Name: 深圳市舒马特科技有限公司

English Name: Shenzhen Shumatt Technology Co., Ltd.

Mob Phone/WeChat: +86-13410541523

HK Telephone: +852-67653519

Telephone: +86-755-23215133

Email: ruby@shumatt.com

Website: www.shumatt.net

Shenzhen Office: 11-12, Floor 14, Building 13, Qinchengda Building, Exit A, Honglang North Subway Station, Bao'an District, Shenzhen, China's Mainland

Shenzhen Office: Exit C, Qiao Touxi Metro Station, NO. 66 Chongqing Road, Fuhai Avenue, Bao'an District, Shenzhen, China Mainland

Hong Kong Office: Jianfa Street Industrial Zone, Tuen Mun, New Territories, Hong Kong, China

After-sales Service Address: Please contact our salesmen to obtain and provide the corresponding product maintenance reasons (Reference: 1.9. F00RJ00222 Injector Solenoid Valve O-ring Warranty Instructions)

Mob/Whatsapp: +86 13410541523 Tel: +8675523215133

Email: ruby@shumatt.com Website: www.shumatt.com

5.2. Sales-men's Contact Information

	No.	Name	WeChat/WhatsApp	Email	
24	1 %	Ruby	+86-13410541523	ruby@shumatt.com	Phys.
	2	lvy	+86-18025309821	sales@shumatt.com	
6	3	Rebecca	+86-18025349821	sales01@shumatt.com	.60
-200-	4	Janny	+86-18028749821	sales02@shumatt.com	900m
	5	Sam	+86-13316859821	Sales8@shumatt.com	
and h	6	Natalie	+86-18938945856	sales15@shumatt.com	40
,500	7 🐃	Ada	+86-1342286353	sales5@shumatt.com	Sec.
	8	Hison Li	+86-18318811871	web@shumatt.com	
egili.	9	Mecca	+86-18938948618	sales11@shumatt.com	300
	10	Eric	+86 18319033618	sales3@shumatt.com	
SI ^A	(1) 11 (3)	Wayne (Joaquín enespañol)	+86-13316959821	wayne@shumatt.com	gift.
	12	Sylvia	+86 18312499884	sales6@shumatt.com	
	1000 ST	Visit <u>http:</u>	//shumatt.com to obtain the late	st information of salesmen	
250	455	PS: Shu	matt's sales-men's emails are all	end with @shumatt.com	St.

6.Copyright Statement

The copyright of any contents (including but not limited to parameters, data, text, charts, images, sounds, or videos, etc.) provided in "FOORJOO222 Injector Solenoid Valve O-ring Technical File" belong to Shenzhen Shumatt Technology Co., Ltd. Without the prior written permission of Shenzhen Shumatt Technology Co., Ltd., you are not allowed to modify any contents in "FOORJOO222 Injector Solenoid Valve O-ring Technical File" in any way. At the same time, any conditions to spread, re-post, display the contents of "FOORJOO222 Injector Solenoid Valve O-ring Technical File" should indicate that the cited article is from Shenzhen Shumatt Technology Co., Ltd., Any actions failure to follow above conditions to use "FOORJOO222 Injector Solenoid Valve O-ring Technical File" will violate the "Copyright Law of the People's Republic of China" and other laws and regulations and the provisions of relevant international conventions.



Mob/Whatsapp: +86 13410541523 Tel: +8675523215133

Email: ruby@shumatt.com Website: www.shumatt.com