

**096010-0700 Fuel Pump Shut-off Solenoid Valve VE Series****Technical File**

SKU1: G1HL10960100700

SKU2: G1DS20960100700



## 096010-0700 Fuel Pump Shut-off Solenoid Valve VE Series

### Technical File

#### Content

|  |   |
|--|---|
| 1. 096010-0700 Fuel Pump Shut-off Solenoid Valve Introduction .....  | 1 |
| 1.1. 096010-0700 Fuel Pump Shut-off Solenoid Valve Basic Information .....                                   | 1 |
| 1.2. 096010-0700 Fuel Pump Shut-off Solenoid Valve Common Part Number .....                                  | 1 |
| 1.3. 096010-0700 Fuel Pump Shut-off Solenoid Valve Specifications and Dimensions .....                       | 2 |
| 1.4. 096010-0700 Fuel Pump Shut-off Solenoid Valve Quality Control .....                                     | 2 |
| 1.5. 096010-0700 Fuel Pump Shut-off Solenoid Valve Customized Service .....                                  | 2 |
| 1.6. 096010-0700 Fuel Pump Shut-off Solenoid Valve Packing List and Package Size .....                       | 3 |
| 1.7. 096010-0700 Fuel Pump Shut-off Solenoid Valve Warranty Instructions .....                               | 3 |
| 1.8. 096010-0700 Fuel Pump Shut-off Solenoid Valve Manufacturer .....  | 4 |
| 2. 096010-0700 Fuel Pump Shut-off Solenoid Valve Technical Support .....                                     | 4 |
| 2.1. 096010-0700 Fuel Pump Shut-off Solenoid Valve Technical Support Obtaining Methods .....                 | 4 |
| 3. 096010-0700 Fuel Pump Shut-off Solenoid Valve Purchase and Delivery .....                                 | 5 |
| 3.1. 096010-0700 Fuel Pump Shut-off Solenoid Valve Purchase Payment Term .....                               | 5 |
| 3.2. 096010-0700 Fuel Pump Shut-off Solenoid Valve Main Sales Markets .....                                  | 5 |
| 3.3. 096010-0700 Fuel Pump Shut-off Solenoid Valve Declaration Requirements .....                            | 5 |
| 3.4. 096010-0700 Fuel Pump Shut-off Solenoid Valve Shipping Ways .....                                       | 5 |
| 3.5. 096010-0700 Fuel Pump Shut-off Solenoid Valve Lead time .....   | 5 |
| 3.6. 096010-0700 Fuel Pump Shut-off Solenoid Valve Logistics Time for Destination Out of China's Areas ..... | 5 |
| 3.7. 096010-0700 Fuel Pump Shut-off Solenoid Valve Packing .....   | 6 |
| 4. 096010-0700 Fuel Pump Shut-off Solenoid Valve Storage Standard .....                                      | 7 |
| 5. Company Information .....   | 7 |
| 5.1. Company Introduction .....  | 8 |
| 5.2. Salesmen's Contact Information .....  | 8 |
| 6. Copyright Statement .....   | 9 |

## 096010-0700 Fuel Pump Shut-off Solenoid Valve VE Series Technical File

### 1. 096010-0700 Fuel Pump Shut-off Solenoid Valve Introduction

#### 1.1. 096010-0700 Fuel Pump Shut-off Solenoid Valve Basic Information

| Title | 096010-0700 Fuel Pump Shut-off Solenoid Valve VE Series | Quality        |
|-------|---|----------------|
| SKU1  | G1HL10960100700   | China Made New |
| SKU2  | G1DS20960100700   | China Made New |

#### 1.2. 096010-0700 Fuel Pump Shut-off Solenoid Valve Common Part Number

##### (1) Fuel Pump Shut-off Solenoid Valve Application Information

| Fuel Pump Part Number | OE Number      | Engine |
|-----------------------|----------------|--------|
| 096000-0440           | 22100-54070    | L      |
| 096000-0520           | S503 13 800A   | XA     |
| 096000-0571           | 22100-54161    | L      |
| 096000-0660           | /              | 721    |
| 096000-0850           | 22100-21910-71 | 2J-T   |
| 096000-0870           | 22100-58200    | 3B     |
| 096000-0930           | 22100-56200    | B      |
| 096000-0941           | 22100-58210    | 3B     |
| 096000-1471           | 22100-54320    | 2L     |
| 096000-1570           | 22300-22060-71 | 2J     |
| 096000-1780           | S517 13 800A   | XA     |
| 096000-1790           | 22300-97341-71 | 2J     |
| 096000-1840           | /              | 4D95L  |
| 096000-2080           | /              | B      |
| 096000-2450           | 22100-58200-1  | /      |
| 096000-2750           | 22100-96400    | 2C     |
| 096000-3320           | 22100-78300-71 | 1Z     |
| 096000-3710           | 22100-56201    | B      |
| 096000-3720           | /              | B      |
| 096000-3800           | 22100-96401    | 2C     |
| 096000-3810           | 22100-58211    | 3B     |

**(2) Fuel Pump Shut-off Solenoid Valve Part Number Common Writing**

096010-0700

**1.3. 096010-0700 Fuel Pump Shut-off Solenoid Valve Specifications and Dimensions**

Fuel Pump Shut-off Solenoid Valve Size: 4cm\*1 cm \*1 cm

Fuel Pump Shut-off Solenoid Valve Box Size: 6 cm \* 2 cm \* 2 cm

Fuel Pump Shut-off Solenoid Valve Net Weight: 50g

Fuel Pump Shut-off Solenoid Valve Gross Weight: 80g

Fuel Pump Shut-off Solenoid Valve Quality: China Made New

Fuel Pump Shut-off Solenoid Valve MOQ: 4 Pieces

**1.4. 096010-0700 Fuel Pump Shut-off Solenoid Valve Quality Control****(1) Fuel Pump Shut-off Solenoid Valve Testing**

All fuel pump shut-off solenoid valve spare parts are tested for electrical characteristics, accuracy, high temperature, low temperature, withstand voltage, leakage, durability, and various working conditions.

**(2) Fuel Pump Shut-off Solenoid Valve Inspection**

The factory inspection of the fuel pump shut-off solenoid valve is undergone full inspection, random inspection, and batch inspection three inspections. Different brands of test benches are used to test the same fuel pump shut-off solenoid valve for a total of no less than three times for factory inspection, and the fuel pump shut-off solenoid valve installation testing environment are progressed in dust-free workshop.

**(3) Fuel Pump Shut-off Solenoid Valve Assembling**

When assembling the pump shut-off solenoid valve, our company strictly adheres to the standard technical specifications of the pump shut-off solenoid valve to ensure that each pump shut-off solenoid valve meets both factory and usage standards.

**1.5. 096010-0700 Fuel Pump Shut-off Solenoid Valve Customized Service****(1) Fuel Pump Shut-off Solenoid Valve Customized Service:** Meet the customized needs of OEM manufacturers for control valve cores and bodies, customized valve body grooves, valve body coding and engraving, valve body QR code engraving, control valve packaging boxes, VCI rust-proof bags and labels customized, etc.**(2) Fuel Pump Shut-off Solenoid Valve Customized Service Requirements:**

Customized fuel pump shut-off solenoid valve packages no less than 100 pieces


Customized fuel pump shut-off solenoid valve sales are not less than 100 pieces

When the customized products involve the need of specify logo, the OEM manufacturer needs to provide trademark authorization and the sample of logo image file.

⚠ Once the customized fuel pump shut-off solenoid valve is sold, it cannot be returned or exchanged if there is no quality problems.

### **1.6.096010-0700 Fuel Pump Shut-off Solenoid Valve Packing List and Package Size**

#### **(1) Fuel Pump Shut-off Solenoid Valve Spare Parts List**

| No.         | 1   | 2   | 3   |
|-------------|---|---|---|
| Image       |  |  |  |
| Name        | Fuel Pump Shut-off Solenoid Valve Assembly  | White Neutral Packaging Box   | White Bubble Bag  |
| Description | Fuel pump shut-off solenoid valve part number: 096010-0700                        | Place the fuel pump shut-off solenoid valve                                       | Preventing damage to the fuel pump camshaft from external forces                    |

⚠ Minors are prohibited from using fuel pump shut-off solenoid valve assemblies, VCI rust-proof bags and packaging boxes to prevent personal injury.

⚠ The fuel pump shut-off solenoid valve packaging boxes are reusable accessories and can be reused.

⚠ VCI rust-proof bags are made of non-degradable materials and should be disposed of properly after use.

### **1.7. 096010-0700 Fuel Pump Shut-off Solenoid Valve Warranty Instructions**

#### **(1) Product Warranty Conditions and Instructions**

It is necessary to provide pictures, videos, or test reports detected by the fuel pump shut-off solenoid valve inspection equipment when the fuel pump shut-off solenoid valve is abnormal during use as evidence to feed back to the salesman.

Abnormal conditions are properly explained such as: 1. Smoke, 2. Engine shake, 3. Difficulty starting the engine, 4. Engine noise, 5. oil leakage etc.

#### **(2) Fuel Pump Shut-off Solenoid Valve Warranty Coverage**

Within 15 days after customer receives the 096010-0700 fuel pump shut-off solenoid valve, if there is a performance failure and the product has no appearance damage, customer can choose to replace it or repair it;

If the 096010-0700 fuel pump shut-off solenoid valve has performance problems during the warranty period (6-12 months), and it is confirmed that it is product's problems after testing, you can contact our salesmen to replace the same model or a reworked product with the same performance for free;

If the fuel pump shut-off solenoid valve house has obvious scratches, it can only be repaired and it will be returned as it is if the product is confirmed to be fault-free.

⚠ Tips: For products not covered by warranty, our company can provide paid maintenance services. For products after paid repaired, the same performance problem will have a free warranty period within 3

months from the date of repairing.

### **(3) Fuel Pump Shut-off Solenoid Valve Out of Warranty Coverage**

- (1) Damage caused by human error during the assembly of the fuel pump shut-off solenoid valve.
- (2) The warranty period has expired.
- (3) Fuel pump shut-off solenoid valve working failure caused by high temperature, high pressure, humidity, rain and snow, saline-alkali land, earthquake, and used in abnormal environment.
- (4) Fuel pump shut-off solenoid valve damage caused by man-made reasons (throwing, strong magnetic field magnetization, set fire).
- (5) Fuel pump shut-off solenoid valve working failure or fuel pump shut-off solenoid valve damaged caused by non-fuel pump shut-off solenoid valve design, technology, manufacturing, quality and other issues.
- (6) Fuel pump shut-off solenoid valve working failure due to system pressure exceeding system approved pressure.
- (7) Fuel pump shut-off solenoid valve working failure caused by impurities (water, lead, aluminum powder, iron powder, sulfide) in the system fuel exceeding the standard requirements.
- (8) Fuel pump shut-off solenoid valve working failure caused by not installing according to the tightening torque specified in the fuel pump maintenance manual (the tightening torque is too large or too small).
- (9) Fuel pump shut-off solenoid valve working failure caused by not following the installation angle specified in the fuel pump maintenance manual.
- (10) Fuel pump shut-off solenoid valve working failure caused by not following the cleaning requirements specified in the fuel pump maintenance manual.
- (11) Fuel pump shut-off solenoid valve malfunction caused by failure to replace wear parts as specified in the fuel pump repair manual

### **1.8. 096010-0700 Fuel Pump Shut-off Solenoid Valve Manufacturer**

**Fuel Pump Shut-off Solenoid Valve Manufacturer:** Shenzhen Shumatt Technology Co., Ltd

### **2. 096010-0700 Fuel Pump Shut-off Solenoid Valve Technical Support**

#### **2.1. 096010-0700 Fuel Pump Shut-off Solenoid Valve Technical Support Obtaining Methods**

- (1) Fuel Pump Shut-off Solenoid Valve Technical File , visit <http://shumatt.com> to get the technical file.
- (2) Fuel Pump Shut-off Solenoid Valve Technical Videos

**Facebook:** Visit <https://www.facebook.com/hison.li> to get the technical videos, constantly follow can get more information.

**YouTube:** [https://www.youtube.com/channel/UCByvYBx7VjV\\_mAfxh\\_Hu-aw](https://www.youtube.com/channel/UCByvYBx7VjV_mAfxh_Hu-aw) to get the technical videos, constantly follow can get more information.

**Shumatt:** Visit <http://shumatt.com> to get the technical videos.

- (3) Fuel Pump Shut-off Solenoid Valve Information Query Software

TruckBook Parts EPC APP, Android/Apple App Store download and install, visit <http://shumatt.com> to get the download and installation tutorial

- (4) Search The Fuel Pump Shut-off Solenoid Valve test data through TruckBook Parts EPC APP.



### 3.096010-0700 Fuel Pump Shut-off Solenoid Valve Purchase and Delivery

#### 3.1.096010-0700 Fuel Pump Shut-off Solenoid Valve Purchase Payment Term

Payment Terms: T/T, PayPal, Alipay, WeChat

**⚠ Please contact our salesmen for specific payment information.**

#### 3.2.096010-0700 Fuel Pump Shut-off Solenoid Valve Main Sales Markets

fuel pump shut-off solenoid valve main sales markets: Asia, Europe, North America, South America, Africa etc.

#### 3.3.096010-0700 Fuel Pump Shut-off Solenoid Valve Declaration Requirements

Shumatt can assist customers to provide the following documents for import customs clearance: contract, invoice, packing list, bill of lading, insurance policy, certificate of origin, etc.

#### 3.4. 096010-0700 Fuel Pump Shut-off Solenoid Valve Shipping Ways

**Destination in China areas:** SF Express, Debon Express, the corresponding logistics company can be provided according to customer requirements in special cases.

**Destinations out of China's areas:** DHL, UPS, FedEx, TNT air, ocean or other shipping methods required by customers.

#### 3.5. 096010-0700 Fuel Pump Shut-off Solenoid Valve Lead time

**Lead time:** Send out within 3 – 7 working days after receiving payment ( Except for special products and special cases ) .

#### 3.6. 096010-0700 Fuel Pump Shut-off Solenoid Valve Logistics Time for Destination Out of China's Areas

**DHL Logistics Time :**

| Country or Region of Departure | Hong Kong, China | Other Countries or Regions of Asia | Australia and New Zealand | Europe | America   | Other Countries |
|--------------------------------|------------------|------------------------------------|---------------------------|--------|-----------|-----------------|
| China's Mainland               | 7 Days           | 7 Days                             | 8 Days                    | 8 Days | 8-12 Days | 7-10 Days       |

**UPS Logistics Time: Country or Region of Departure: China's Mainland**

| Country of Destination | Estimated Arrival Time | Country of Destination | Estimated Arrival Time | Country of Destination | Estimated Arrival Time |
|------------------------|------------------------|------------------------|------------------------|------------------------|------------------------|
| Japan                  | 3 Days                 | UK                     | 5-7 Days               | Egypt                  | 5-7 Days               |
| Turkey                 | 5-7 Days               | Singapore              | 3 Days                 | Switzerland            | 5-7 Days               |
| Bahrain                | 5-7 Days               | Latvia                 | 7-10 Days              | New Zealand            | 7-10 Days              |
| Sri Lanka              | 5-7 Days               | Thailand               | 3 Days                 | Austria                | 5-7 Days               |
| Romania                | 5-7 Days               | Vietnam                | 3-5 Days               | Estonia                | 5-7 Days               |
| Malaysia               | 3-5 Days               | Israel                 | 5-7 Days               | Mexico                 | 7-10 Days              |
| France                 | 5-7 Days               | America                | 5-7 Days               | United Arab Emirates   | 5-7 Days               |

|             |           |             |           |              |           |
|-------------|-----------|-------------|-----------|--------------|-----------|
| Italy       | 5-7 Days  | Netherlands | 5-7 Days  | Bengal       | 7-10 Days |
| Lebanon     | 5-7 Days  | Philippine  | 3-5 Days  | Greece       | 7-10 Days |
| South Korea | 3 Days    | Spain       | 5-7 Days  | Myanmar      | 5-7 Days  |
| Canada      | 5-7 Days  | Germany     | 5-7 Days  | Saudi Arabia | 7-10 Days |
| Portugal    | 5-7 Days  | Australia   | 5-7 Days  | South Africa | 7-10 Days |
| Denmark     | 5-7 Days  | Belgium     | 5-7 Days  | Ukraine      | 7-10 Days |
| India       | 7-10 Days | Qatar       | 7-10 Days | Poland       | 5-7 Days  |
| Indonesia   | 3-5 Days  | Morocco     | 7-10 Days | Pakistan     | 7-10 Days |
| Kuwait      | 7-10 Days | /           | /         | /            | /         |

▲ The logistics time is for reference only, subjects are according to the actual arrival.

### 3.7. 096010-0700 Fuel Pump Shut-off Solenoid Valve Packing

**Domestic express packaging:** Usually wrapped in waterproof scotch tape, such as picture No.1.

**International express packaging:** Wrapped with waterproof yellow tape After wrapping the black protective film, such as picture No. 2.

**Pallet Shipping:** Use fumigation free and recycling trays that meet export requirements, and use white wrapping protective film to wrap and bind with cable ties for the outside, such as picture No. 3, also, the products can be packaged according to customers' requirements.

▲ The packing tray is made of plastic and can be recycled.

▲ Transparent tape, yellow tape, black wrapping protective film, white wrapping protective film are non-degradable materials, please dispose of them properly.

▲ Minors are prohibited from using transparent tape, yellow tape, black wrapping protective film, and white wrapping protective film to avoid personal injury.

| No.         | 1   | 2  | 3   |
|-------------|---|--|---|
| Image       |  |  |                              |
| Name        | Domestic Express Packaging  | International Express Packaging  | Pallet Shipping   |
| Description | Wrapped by transparent tape   | Wrapped with yellow tape after wrapping black protective film                        | Use pallet that meet export requirements, and use white wrapping protective film to wrap and bind with cable ties |

**4.096010-0700 Fuel Pump Shut-off Solenoid Valve Storage Standard****(1) Choose a suitable storage place**

The warehouse and cargo yard where the fuel pump shut-off solenoid valve is stored should be kept clean and dry, and away from the factory buildings that generate harmful gases and dust; do not mix with acids, alkalis, salts and other substances; the storage place should have a good drainage system; the cargo yard should be flattened with gravel or furnace ash etc. to enhance the water permeability of the surface layer to keep the reservoir area dry.

**(2) Strict requirements of warehousing**

Strict inspections should be carried out when the fuel pump shut-off solenoid valves are put into storage, the surface cleaning work should be done well to remove water traces, oil stains, ash and other dirt, remove the rust and do anti-rust treatment in time. Packaged fuel pump shut-off solenoid valve must be protected from damage.

**(3) Keep the warehouse dry and preventing moisture**

The relative humidity is usually below 70% for the fuel pump shut-off solenoid valves placed in the room, and the corrosion of the fuel pump shut-off solenoid valves is significantly reduced.

Fuel pump shut-off solenoid valves must be stored in the warehouse, and they are forbidden to store in the same warehouse with commodities with high water content.

**(4) Stack Properly**

After the fuel pump shut-off solenoid valve is exposed to rain, the corrosion rate will increase significantly. The purpose of sealing is to isolate the fuel pump shut-off solenoid valve from rainwater and humid air, so the warehouse window should be checked in time to avoid rainwater entering the warehouse.

If the fuel pump shut-off solenoid valve package is damaged, it should be repaired or replaced; when the package is damp, the packaging material should be dried; if the original anti-corrosion and oil applied at the factory is found to be damaged or dried up, it should be cleaned and re-applied oil in time.

- ▲ It is forbidden to leave the fuel pump shut-off solenoid valve exposed in the air for a long time.
- ▲ It is forbidden to store acid, alkali, salt and other substances together with the fuel pump shut-off solenoid valve.
- ▲ The unpacked fuel pump shut-off solenoid valve must be rust-proof during secondary storage.

**5. Company Information**



## 5.1. Company Introduction

**Chinese Name:** 深圳市舒马特科技有限公司

**English Name:** Shenzhen Shumatt Technology Co., Ltd

❑ **Mob Phone/WeChat:** +86-13410541523

❑ **HK Telephone:** +852-67653519

❑ **Telephone:** +86-755-23215133

❑ **Email:** ruby@shumatt.com

❑ **Website:** [www.shumatt.com](http://www.shumatt.com)

📍 **Shenzhen Office:** 11-12, Floor 14, Building 13, Qinchengda Building, Exit A, Honglang North Subway Station, Bao'an District, Shenzhen, China's Mainland

📍 **Shenzhen Office:** Exit C, Qiao Touxi Metro Station, NO. 66 Chongqing Road, Fuhai Avenue, Bao'an District, Shenzhen, China Mainland

📍 **Hong Kong Office:** Jianfa Street Industrial Zone, Tuen Mun, New Territories, Hong Kong, China

📍 **After-sales Service Address:** Please contact our salesmen to obtain and provide the corresponding product maintenance reasons ( Reference: [1.7. 096010-0700 Fuel Pump Shut-off Solenoid Valve Warranty Instructions](#) )

## 5.2. Salesmen's Contact Information

| No. | Name                         | WeChat/WhatsApp | Email  |
|-----|------------------------------|-----------------|--|
| 1   | Ruby                         | +86-13410541523 | <a href="mailto:ruby@shumatt.com">ruby@shumatt.com</a>       |
| 2   | Ivy                          | +86-18025299821 | <a href="mailto:sales@shumatt.com">sales@shumatt.com</a>     |
| 3   | Rebecca                      | +86-18025349821 | <a href="mailto:sales01@shumatt.com">sales01@shumatt.com</a> |
| 4   | Janny                        | +86-18028749821 | <a href="mailto:sales02@shumatt.com">sales02@shumatt.com</a> |
| 5   | Sam                          | +86-13316859821 | <a href="mailto:sales8@shumatt.com">Sales8@shumatt.com</a>   |
| 6   | Natalie                      | +86-18938945856 | <a href="mailto:sales15@shumatt.com">sales15@shumatt.com</a> |
| 7   | Ada                          | +86-1342286353  | <a href="mailto:sales5@shumatt.com">sales5@shumatt.com</a>   |
| 8   | Hison Li                     | +86-18318811871 | <a href="mailto:web@shumatt.com">web@shumatt.com</a>         |
| 9   | Mecca                        | +86-18938948618 | <a href="mailto:sales11@shumatt.com">sales11@shumatt.com</a> |
| 10  | Eric                         | +86 18319033618 | <a href="mailto:sales3@shumatt.com">sales3@shumatt.com</a>   |
| 11  | Wayne ( Joaquín en español ) | +86-13316959821 | <a href="mailto:wayne@shumatt.com">wayne@shumatt.com</a>     |
| 12  | Sylvia                       | +86 18312499884 | <a href="mailto:sales6@shumatt.com">sales6@shumatt.com</a>   |

Visit <http://shumatt.com> to obtain the latest information of salesmen

**PS:** Shumatt's salesmen's emails are all end with [@shumatt.com](mailto:@shumatt.com)

## 6. Copyright Statement

The copyright of any contents (including but not limited to parameters, data, text, charts, images, sounds or videos, etc.) provided in "**096010-0700 Fuel Pump Shut-off Solenoid Valve VE Series Technical File**" belong to Shenzhen Shumatt Technology Co., Ltd. Without the prior written permission of Shenzhen Shumatt Technology Co., Ltd., you are not allowed to modify any contents in "**096010-0700 Fuel Pump Shut-off Solenoid Valve VE Series Technical File**" in any way. At the same time, any conditions to spread, repost, display the contents of "**096010-0700 Fuel Pump Shut-off Solenoid Valve VE Series Technical File**" should indicate that the cited article is from Shenzhen Shumatt Technology Co., Ltd., Any actions failure to follow above conditions to use "**096010-0700 Fuel Pump Shut-off Solenoid Valve VE Series Technical File**" will violate the "*Copyright Law of the People's Republic of China*" and other laws and regulations and the provisions of relevant international conventions.